
Command Reference: SetReservoirAggregate ()

Set reservoir aggregate parts

StateMod Command

Version 3.09.01, 2010-02-01

The SetReservoirAggregate () command sets reservoir aggregate part identifier data for a reservoir. Aggregate reservoirs are defined as a combination of other reservoirs and may be used, for example, to aggregate stock ponds or other small reservoirs. This command should be specified before commands that need aggregate information during processing (e.g., those that read data from HydroBase). The following dialog is used to edit the command and illustrates the syntax of the command.



SetReservoirAggregate() Command Editor

The command syntax is as follows:

SetReservoirAggregate(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ID	The reservoir identifier to associate with	None – must be specified.
	the aggregate part identifiers.	
PartIDs	The list of part identifiers to comprise the	None – must be specified.
	aggregate.	
IfNotFound	Used for error handling, one of the	Warn
	following:	
	• Fail – generate a failure message if	
	the ID is not matched	
	• Ignore – ignore (don't add and	
	don't generate a message) if the ID is	
	not matched	
	Warn – generate a warning message	
	if the ID is not matched	