
## Command Reference: SetStreamEstimateStation()

## Set stream estimate station data

**StateMod Command** 

Version 3.09.01, 2010-02-01

The SetStreamEstimateStation() command sets data in existing stream estimate stations or adds a new stream estimate station. The following dialog is used to edit the command and illustrates the syntax of the command.



SetStreamEstimateStation

SetStreamEstimateStation() Command Editor

The command syntax is as follows:

SetStreamEstimateStation(Parameter=Value,...)

## **Command Parameters**

Parameter	Description	Default
ID	A single stream estimate station identifier to match or a pattern using wildcards (e.g., 20*).	None – must be specified.
Name	The name to be assigned for all matching stream estimate stations.	If not specified, the original value will remain.
RiverNodeID	The river node identifier to be assigned for all matching stream estimate stations.	If not specified, the original value will remain.
DailyID	The daily identifier to be assigned for all matching stream estimate stations.	If not specified, the original value will remain.
IfNotFound	<ul> <li>Used for error handling, one of the following:</li> <li>Add – add the stream estimate station if the ID is not matched and is not a wildcard</li> <li>Fail – generate a failure message if the ID is not matched</li> <li>Ignore – ignore (don't add and don't generate a message) if the ID is not matched</li> <li>Warn – generate a warning message if the ID is not matched</li> </ul>	Warn