Command Reference: ReadWellStationsFromList()


Read well stations data from a list file

StateMod Command

Version 4.00.00, 2016-05-19

The ReadWellStationsFromList() command reads a list of well stations from a delimited list file and defines well stations in memory. The well stations can then be manipulated and output with other commands. Reading from a list is more general than reading from a StateMod file.

The following dialog is used to edit the command and illustrates the syntax of the command.



ReadWellStationsFromList() Command Editor

ReadWellStationsFromList

The command syntax is as follows:

ReadWellStationsFromList(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ListFile	The name of the list file to be read.	None – must be specified.
IDCol	The column number (1+) containing the	None – must be specified.
	well station identifiers.	
NameCol	The column number (1+) containing the	None – optional (name will be
	well station names.	initialized to blank).
DiversionIDCol	The column number (1+) containing the diversion identifiers associated with the well stations. This is needed in some cases to determine when a location is a diversion with supplemental well supply, for example, when processing well rights.	None – optional (diversion ID will be initialized to blank).
Top	Specify the number of rows to read, useful for testing.	Read all rows.

At a minimum, the list file must contain a column with well station identifiers. Lines starting with the # character are treated as comments. If the first line's values are surrounded by double quotes, the line is assumed to indicate column headings.

A sample list file is shown below:

```
# sp2007L AugRchWells.csv
# rrb Augmentation and recharge wells from SmOpr
  SmOpr
       State of Colorado
       Version: 1.00
       Last revision date: 2006/10/27
\# \text{ rrb } 2008/10/08 \text{ count} = 17 + 4 21
0102522_AuW ,"RIVERSIDE AUG
0102528_AuW ,"FT MORGAN CNL AUG PLAN ",' ', ' ',
0102529_AuW ,"UPPER PLATTE BEAVER AUG ",' ', ' ', ' ', ' ', ' ', ' NA'
0102535_ReW ,"LOWER PLATTE BEAVER AUG ",' ', ' ', ' ', ' ', ' ', ' NA'
0102535_AuW ,"LOWER PLATTE BEAVER AUG ",' ', ' ', ' ', ' ',
6402015_ReW ,"TAMARAK
6402027_ReW , "OVERLAND
6402519 ReW ,"DINSDALE AUG
```