Command Reference: ReadWellHistoricalPumpingTSMonthlyFromStateMod()


Read well historical pumping time series (monthly) data from a StateMod file

StateMod Command

Version 3.09.00, 2010-01-26

The ReadWellHistoricalPumpingTSMonthlyFromStateMod() command reads well historical pumping time series (monthly) and defines the data in memory. This command is used when estimating average efficiencies and calculating demand time series. All time series are read, whether or not they match the list of well stations. This command is equivalent to the ReadWellHistoricalPumpingTSMonthlyFromStateCU() command – use the commands as appropriate depending on which data set file is being read (the file format is the StateMod time series file format).

The following dialog is used to edit the command and illustrates the syntax of the command.



ReadWellHistoricalPumpingTSMonthlyFromStateMod() Command Editor

The command syntax is as follows:

ReadWellHisoricalPumpingTSMonthlyFromStateMod(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod well historical pumping time	None – must be
	series (monthly) file to read.	specified.