
Command Reference: ReadReservoirStationsFromList()

Read reservoir stations data from a list file

StateMod Command

Version 3.09.01, 2010-02-01

The ReadReservoirStationsFromList() command reads a list of reservoir stations from a delimited list file and defines reservoir stations in memory. The reservoir stations can then be manipulated and output with other commands. The following dialog is used to edit the command and illustrates the syntax of the command.



ReadReservoirStationsFromList() Command Editor

The command syntax is as follows:

ReadReservoirStationsFromList(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ListFile	The name of the list file to be read.	None – must be specified.
IDCol	The column number (1+) containing the	None – must be specified.
	reservoir station identifiers.	
NameCol	The column number (1+) containing the	None – optional (name will be
	reservoir station names.	initialized to blank).

At a minimum, the list file must contain a column with diversion station identifiers. Lines starting with the # character are treated as comments. If the first line's values are surrounded by double quotes, the line is assumed to indicate column headings.

A sample list file is shown below:

```
# Reservoir stations as a list file
#
"ID","Name"
203536,"Reservoir 1"
203558,"Reservoir 2"
...
```