
Command Reference: WriteInstreamFlowRightsToStateMod()

Write instream flow rights data to a StateMod file

StateMod Command

Version 3.09.01, 2010-02-01

The WriteInstreamFlowRightsToStateMod() command writes instream flow rights that have been defined to a StateMod instream flow rights file. The following dialog is used to edit the command and illustrates the syntax of the command.



WriteInstreamFlowRightsToStateMod() Command Editor

The command syntax is as follows:

 ${\tt WriteInstreamFlowRightsToStateMod\,(Parameter=Value,...)}$

Command Parameters

Parameter	Description	Default
OutputFile	The name of the output file to write,	None – must be specified.
	surrounded by double quotes.	
WriteHow	OverwriteFile if the file should be	OverwriteFile
	overwritten or UpdateFile if the file	
	should be updated, resulting in the	
	previous header being carried forward.	