# Command Reference: SetCULocationClimateStationWeightsFromList()


## Set CU Location climate station weights from data in a list file

#### StateCU and StateMod Command

Version 3.09.00, 2010-01-24

The SetCULocationClimateStationWeightsFromList() command reads climate station weights from a list file and sets the information for CU Locations.

The following dialog is used to edit the command and illustrates the syntax of the command.



SetCULocationClimateStationWeightsFromLis

### SetCULocationClimateStationWeightsFromList() Command Editor

An example list file for setting data using Region1 (county) is shown below:

```
# RGDSS.WTS - Hand built climate weights file for the RGDSS analysis

# Base on Climate Assignment memo prepared 9/21/99

# ID, Lat, County, HUC, TempWt, PrecWt
3951,37.7667,SAN JUAN,13010001,1.000,1.000
3951,37.7667,HINSDALE,13010001,1.000,1.000
2184,37.6833,RIO GRANDE,13010001,0.700,0.700
```

An example list file for setting data by CU location ID is shown below:

```
#Date and Time |Thu May 03 11:31:37 2007

#Input Polygon Theme |2001_Acreage_CW

#Polygon ID Field |PARCEL_ID

#Climate Weights Workspace |S:\CDSS\GIS\Climate_Wts

#Orographic Grids Workspace |#

0200552,2220,0.19,1

0200552,3553,0.39,1

0200552,5116,0.42,1

0200805,1179,0.39,1

0200805,2220,0.1,1

0200805,3553,0.51,1
```

The command syntax is as follows:

SetCULocationClimateStationWeightsFromList(Parameter=Value,...)

#### **Command Parameters**

Parameter	Description	Default
ListFile	The name of the input file to read, surrounded by double quotes.	None – must be specified.
IDCol	The column number (1+) containing the climate station identifier.	None – must be specified. If specified, Region1Col and Region2Col should not be specified.
Region1Col	The column number (1+) containing the Region1 identifier.	If specified, the ID column should not be specified.
Region2Col	The column number (1+) containing the Region2 identifier.	If specified, the ID column should not be specified.
TempWtCol	The column number (1+) containing the temperature station weights.	If not specified, the original values remain.
PrecWtCol	The column number (1+) containing the precipitation station weights.	If not specified, the original values remain.
Orographic TempAdjCol	The column number (1+) containing the orographic temperature adjustment factor (DEGF/1000 FT).	If not specified, the original values remain.
Orographic PrecAdjCol	The column number (1+) containing the orographic precipitation adjustment factor (fraction).	If not specified, the original values remain.
IfNotFound	<ul> <li>Used for error handling, one of the following:</li> <li>Fail – generate a failure message if the ID pattern is not matched</li> <li>Ignore – ignore (don't generate a message) if the ID pattern is not matched</li> <li>Warn – generate a warning message if the ID pattern is not matched</li> </ul>	Warn