
Command Reference: SetCULocation()

Set CU Location data

StateCU Command Version 3.08.02, 2010-01-02

The SetCULocation () command sets data in existing CU Locations or adds a new CU Location. The following dialog is used to edit the command and illustrates the syntax of the command.



SetCULocation() Command Editor

The command syntax is as follows:

SetCULocation(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ID	A single CU Location identifier to match	None – must be specified.
	or a pattern using wildcards (e.g., 20*).	
Latitude	The latitude to be assigned for all	If not specified, the original
	matching CU Locations.	value will remain.
Elevation	The elevation to be assigned for all	If not specified, the original
	matching CU Locations.	value will remain.
Region1	The Region1 to be assigned for all	If not specified, the original
	matching CU Locations.	value will remain.
Region2	The Region2 to be assigned for all	If not specified, the original
	matching CU Locations.	value will remain.
Name	The name to be assigned for all matching	If not specified, the original
	CU Locations.	value will remain.
AWC	The available water content (AWC) to	If not specified, the original
	be assigned for all matching CU	value will remain.
	Locations.	
IfNotFound	Used for error handling, one of the	Warn
	following:	
	• Fail – generate a failure message if	
	the ID pattern is not matched	
	• Ignore – ignore (don't generate a	
	message) if the ID pattern is not	
	matched	
	Warn – generate a warning message	
	if the ID pattern is not matched	