
Command Reference: FillReservoirRight()

Fill reservoir right data

StateMod Command

Version 3.09.01, 2010-02-01

The FillReservoirRight() command fills missing data in existing reservoir rights. The following dialog is used to edit the command and illustrates the syntax of the command.



FillReservoirRight() Command Editor

FillReservoirRight

The command syntax is as follows:

FillReservoirRight(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ID	A single reservoir right identifier to match or a	None – must be specified.
	pattern using wildcards (e.g., 20*).	
Name	The name to be assigned for all matching	If not specified, the original
	reservoir right identifiers with missing name.	value will remain.
StationID	The reservoir station identifier to be assigned	If not specified, the original
	for all matching reservoir right identifiers with	value will remain.
	missing reservoir station identifier.	
Administration	The administration number to be assigned for	If not specified, the original
Number	all matching reservoir right identifiers with	value will remain.
	missing administration number.	
Decree	The water right decree to be assigned for all	If not specified, the original
	matching reservoir right identifiers with	value will remain.
	missing administration decree.	
OnOff	The on/off switch to be assigned for all	If not specified, the original
	matching reservoir right identifiers with	value will remain.
	missing on/off switch, either 1 for on or 0 for	
	off, a positive 4-digit year to turn the right on	
	starting in the year, or a negative 4-digit year to	
	turn the right off starting in the year.	
AccountDist	The account distribution option to be assigned	If not specified, the original
	for all matching reservoir rights (see StateMod	value will remain.
	documentation).	
RightType	The reservoir right type to be assigned for all	If not specified, the original
	matching reservoir rights (see StateMod	value will remain.
	documentation).	
FillType	The reservoir right fill type to be assigned for	If not specified, the original
	all matching reservoir rights (see StateMod	value will remain.
	documentation).	
OpRightID	The out-of-priority associated operational right	If not specified, the original
	(see StateMod documentation).	value will remain.
IfNotFound	Used for error handling, one of the following:	Warn
	• Fail – generate a failure message if the ID	
	is not matched	
	• Ignore – ignore (don't generate a	
	message) if the ID is not matched	
	Warn – generate a warning message if the	
	ID is not matched	