
Command Reference: setCULocationDelayTableAssignmentsFrom StateMod()

Set CU Location delay table assignments from data in a StateMod file

StateCU Command

Version 01.07.00, 2004-03-31, Color, Acrobat Distiller

The setCULocationDelayTableAssignmentsFromStateMod() command reads delay table assignment data from a StateMod diversion or well stations file and transfers the data to a CU Location. The following dialog is used to edit the command and illustrates the syntax of the command.



setCULocationDelayTableAssignmentsFromStateMod

setCULocationDelayTableAssignmentsFromStateMod() Command Editor

The command syntax is as follows:

setCULocationDelayTableAssignmentsFromStateMod(param=value,...)

Command Parameters

Parameter	Description	Default
InputFile	The name of the input file to read,	None – must be specified.
	surrounded by double quotes.	