## Command Reference: ReadWellRightsFromStateMod()

## Read well right data from a StateMod well rights file

## StateCU and StateMod Command

Version 3.09.00, 2010-01-00


The ReadWellRightsFromStateMod() command reads well rights from a StateMod well rights file. The well rights can then be manipulated and output with other commands. Current procedures for processing some data files involve utilizing StateMod well rights file(s) as input rather than rereading well rights from HydroBase. This ensures that the content and quality of the well rights file can be verified and is used consistently when processing various model files. For example, StateMod well rights files may be used for the following purposes:

- 1. Turning off groundwater only parcels irrigated lands (crop pattern and irrigation practice acreage time series) prior to a specific year of parcel data. Parcels that do not have a well right in a year are estimated to not be irrigated for the year (and prior years). This step typically uses a well rights file that has NOT had water rights for various parcel years merged data for a single parcel year will be used. See the
  - WriteWellRightsToStateMod(...,WriteDataComments=True,...) command.
- 2. Setting the pumping maximum in the irrigation practice time series. This step typically uses a well rights file that includes well rights for different parcel years that have been merged. For example, well rights from 1998 parcels and those from 2002 parcels are merged to not double count rights. See the MergeWellRights() command.
- 3. Setting the well station capacity to the total of the well rights. This step may use a merged rights file or one that has been aggregated (well rights summed into administration number classes). Aggregation is used in some data sets to decrease the complexity of the model. However, aggregation is generally NOT performed in data sets such as the South Platte where augmentation plans reference individual well rights. See the AggregateWellRights() command.

The well rights files mentioned above are typically written to separate files with unique names. To support cases 1 and 2 above, the StateMod file should include "data comments" on the far right, which include the well to parcel matching data (parcel year, class, parcel ID). An excerpt from a well rights file with this information is shown below:

#>	ID	Name	Struct	Admin # Dec	ree C	n/Off	PYrC	ls	PID
#>		eb	ebeb	eb	eb-	ex	bexb	ex	be
#>									
#>									
2005	5001	W0006 WELL NO 01	200812	31592.00000	2.34	1936	1936	1	3107
2005	5001	W0006 WELL NO 01	200812	38836.00000	1.23	1956	1936	1	3107
2005	5001	W0006 WELL NO 01	200812	31592.00000	2.34	1936	1998	2	11016
2005	5001	W0006 WELL NO 01	200812	38836.00000	1.23	1956	1998	2	11016
2005	5001	W0006 WELL NO 01	200812	31592.00000	1.19	1936	2002	2	20901
2005	5001	W0006 WELL NO 01	200812	38836.00000	0.62	1956	2002	2	20901
2005	5001	W0006 WELL NO 01	200812	31592.00000	1.15	1936	2002	5	20902
2005	5001	W0006 WELL NO 01	200812	38836.00000	0.61	1956	2002	5	20902

The following dialog is used to edit the command and illustrates the syntax of the command.



ReadWellRightsFromStateMod() Command Editor

The command syntax is as follows:

ReadWellRightsFromStateMod(Parameter=Value,...)

## **Command Parameters**

Parameter	Description	Default
InputFile	The name of the StateMod well rights file to be	None – must be
	read.	specified.
Append	Indicate whether the data should be appended to	True
	in-memory well rights. Specify False if	
	processing well rights for independent tasks and	
	the current task should not be influenced by	
	previously read well rights.	