Command Reference: ReadDiversionDemandTSMonthlyFromStateMod()


Read diversion demand time series (monthly) data from a StateMod file

StateMod Command

Version 3.09.01, 2010-02-01

The ReadDiversionDemandTSMonthlyFromStateMod() command reads diversion demand time series (monthly). All time series are read, whether or not they match the list of diversion stations.

The following dialog is used to edit the command and illustrates the syntax of the command.



ReadDiversionDemandTSMonthlyFromStateMod() Command Editor

The command syntax is as follows:

ReadDiversionDemandTSMonthlyFromStateMod(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod diversion demand time	None – must be
	series (monthly) file to read.	specified.