Command Reference: ReadStreamGageStationsFromStateMod()


Read stream gage station data from a StateMod stream gage stations file

StateMod Command

Version 3.09.01, 2010-02-01

The ReadStreamGageStationsFromStateMod() command reads a list of stream gage stations from a StateMod stream gage stations file and defines stream gage stations in memory. The stream gage stations can then be manipulated and output with other commands.

The following dialog is used to edit the command and illustrates the syntax of the command.



ReadStreamGageStationsFromStateMod() Command Editor

The command syntax is as follows:

ReadStreamGageStationsFromStateMod(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
InputFile	The name of the StateMod stream gage stations	None – must be
	file to be read.	specified.