## Command Reference: SetInstreamFlowRight()


## Set instream flow right data

## StateMod Command

Version 3.09.01, 2010-03-14, Color, Acrobat Distiller

The SetInstreamFlowRight() command sets data in existing instream flow rights or adds a new instream flow right. If a new right is added, it is added in alphabetical order according to the right identifier. Instream flow rights may be defined for a variety of reasons for modeling purposes where a flow needs to be ensured.

The following dialog is used to edit the command and illustrates the syntax of the command.



SetInstreamFlowRight() Command Editor

Command Reference - SetInstreamFlowRight() - 1

The command syntax is as follows:

SetInstreamFlowRight(Parameter=Value,...)

## **Command Parameters**

Parameter	Description	Default
ID	A single instream flow right identifier to match	None – must be specified.
	or a pattern using wildcards (e.g., 20*).	
Name	The name to be assigned for all matching	If not specified, the original
	instream flow rights.	value will remain.
StationID	The instream flow station identifier to be	If not specified, the original
	assigned for all matching instream flow rights.	value will remain.
Administration	The administration number to be assigned for	If not specified, the original
Number	all matching instream flow rights.	value will remain.
Decree	The water right decree to be assigned for all	If not specified, the original
	matching instream flow rights.	value will remain.
OnOff	The on/off switch value to be assigned for all	If not specified, the original
	matching instream flow rights, either 1 for on	value will remain.
	or 0 for off, a positive 4-digit year to turn the	
	right on starting in the year, or a negative 4-	
	digit year to turn the right off starting in the	
	year.	
IfNotFound	Used for error handling, one of the following:	Warn
	• Add – add the instream flow right if the ID	
	is not matched and is not a wildcard	
	• Fail – generate a failure message if the	
	ID is not matched	
	• Ignore – ignore (don't add and don't	
	generate a message) if the ID is not	
	matched	
	• Warn – generate a warning message if the	
	ID is not matched	
IfFound	Used for error handling, one of the following:	Warn
	• Set – set the instream flow right,	
	overwriting previous values if the ID is	
	matched	
	• Fail – generate a failure message if the	
	ID is matched	
	• Ignore – ignore (don't add and don't	
	generate a message) if the ID is matched	
	Warn – generate a warning message if the	
	ID is matched	