
Command Reference: SetOutputPeriod()

Set the Output Period for Time Series

General Command

Version 3.08.02, 2010-01-07

The SetOutputPeriod() command sets the output period for time series. Specifying the output period is necessary when creating model files or filling an extended period (time series will not automatically be extended by fill commands). The following dialog is used to edit this command and illustrates the syntax of the command. Note that the output period should always use calendar month and year, even if other than calendar year are used for output (see SetOutputYearType()).



SetOutputPeriod

SetOutputPeriod() Command Editor

The command syntax is as follows:

SetOutputPeriod(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
OutputStart	The output period start, in a standard	None – must be specified.
	date/time format. The precision of this	
	value should match that of data because	
	it is used to iterate through the data. For	
	example, if monthly data are being	
	processed, specify the OutputStart	
	using year and month.	
OutputEnd	The output period end, in a standard	None – must be specified.
	date/time format. The precision of this	
	value should match that of data because	
	it is used to iterate through the data. For	
	example, if monthly data are being	
	processed, specify the OutputStart	
	using year and month.	