Command Reference: CheckInstreamFlowStations()


Check instream flow stations data for problems

StateMod Command

Version 3.09.01, 2010-02-01

The CheckInstreamFlowStations() command checks instream flow stations data for problems. The command should usually be used with a WriteCheckFile() command at the end of a command file.

The following dialog is used to edit the command and illustrates the syntax of the command.



CheckInstreamFlowStations() Command Editor

Command Reference – CheckInstreamFlowStations() - 1

The command syntax is as follows:

CheckInstreamFlowStations(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
ID	The identifier for the location(s) to check. Use * to match a	None – must be
	pattern.	specified.
IfNotFound	One of the following:	Warn
	• Fail – generate a failure message if the location identifier	
	is not matched	
	• Ignore – ignore (don't generate a message) if the location	
	identifier is not matched	
	Warn – generate a warning message if the location	
	identifier is not matched	

The following excerpt from a command file illustrates how instream flow stations can be checked and written to a StateMod file:

```
#
# Create instream flow stations file
#
WriteInstreamFlowStationsToStateMod(OutputFile="..\STATEMOD\cm2005.ifs")
#
# Check the results
CheckInstreamFlowStations (ID="*")
WriteCheckFile(OutputFile="ifs.commands.StateDMI.check.html")
```