## Command Reference: FillWellStationsFromNetwork()

## Fill well station data from a StateMod network

**StateMod Command** 

Version 3.09.01, 2010-02-01

The FillWellStationsFromNetwork() command fills missing data in well stations, using a StateMod network for data. This command is usually used after filling from other sources (e.g., HydroBase), because the information in the network file may have been specified mainly for the diagram and therefore does not necessarily match official data sources. It is assumed that the network has been read in a previous command (e.g., when the list of well stations was originally read).

The following dialog is used to edit the command and illustrates the syntax of the command.



FillWellStationsFromNetwork() Command Editor

FillWellStationsFromNetwork

The command syntax is as follows:

FillWellStationsFromNetwork(Parameter=Value,...)

## **Command Parameters**

Parameter	Description	Default
ID	A single well station identifier to match	None – must be specified.
	or a pattern using wildcards (e.g., 20*).	
IfNotFound	Used for error handling, one of the	Warn
	following:	
	• Fail – generate a failure message if	
	the ID is not matched	
	• Ignore – ignore (don't add and	
	don't generate a message) if the ID is	
	not matched	
	• Warn – generate a warning message	
	if the ID is not matched	

The following example illustrates how to fill well station names from the network. A command to fill from HydroBase or another source will often be run before the second command below.

```
ReadWellStationsFromNetwork(InputFile="sp2005.net")
FillWellStationsFromNetwork(ID="*")
```