Command Reference: TS X = readTimeSeries()

Read a Single Time Series from an Input Type

Version 06.08.02, 2004-07-29, Color, Acrobat Distiller

The TS X = readTimeSeries () command is used to read a single time series from any input type. This generalized command is useful for converting time series identifiers from the TSTool interface into read commands that assign an alias to a time series. Because the command is generic, it does not offer specific parameters that may be found in read commands for specific input types. Use the specific read commands where available. The following dialog is used to edit the command and illustrates the syntax of the command.



readTimeSeries() Command Editor

TS_readTimeSeies

The command syntax is as follows:

TS X = readTimeSeries("TSID")

Command Parameters

Parameter	Description	Default
X	The alias assigned to the time series.	None – must be specified.
TSID	The time series identifier of the time	None – must be specified.
	series to read. The identifier should	
	include the input type (and input name) if	
	required. See the input type appendices	
	for examples of time series identifiers for	
	various input types.	

A sample commands file is as follows:

TS Alamosa = readTimeSeries("08235350.USGS.Streamflow.Day~HydroBase")

readTimeSeries() Command		TSTool Documentation
	This page is intentionally blank.	