Appendix: HydroBase Datastore

2012-12-18

Overview

This appendix describes the HydroBase datastore, which is being phased in to replace the HydroBase "input type". The newer datastore design is more flexible. Some issues remain before moving completely to the datastore concept and consequently the configuration of a HydroBase datastore is an optional feature that is not enabled by default (to enable, remove the <code>Enabled=False</code> property in the example configuration files provided with the software). Technical issues mainly involve how to change the traditional HydroBase login dialog and best practices for naming datastores when dealing with dated versions of HydroBase.

The HydroBase database contains stored procedures and views suitable for the following users (accounts):

- CDSS user (SQL Server login cdss, password cdss%tools) is a service account that exposes HydroBase data through stored procedures and views appropriate for decision support system projects. HydroBase CDSS view names have the prefix vw_CDSS. This is the default account when using the HydroBase datastore.
- HBGuest user (SQL Server login HBGuest, password 1HBGuest) is a service account that exposes HydroBase data through stored procedures and views appropriate for general database users. HydroBase HBGuest view names have the prefix vw_CDSS. See the C:\CDSS\doc\HydroBase\UserManual\HBGuest.pdf documentation (available after installing the HydroBase DVD) for an overview of HBGuest configuration and database access.

A general rule of thumb is that the CDSS account should be used for full TSTool functionality; however, the HBGuest account can be used to query views that are not available via the CDSS account (e.g., the ww_HBGuest_StructureAssocWDID table provides information about augmentation plans and other structure groups).

TSTool connections for the above HydroBase accounts can be figured in several ways:

• CDSS user:

- Oconfigure as the HydroBase "input type". This is the default legacy behavior when HydroBase is enabled, and relies on the user selecting a HydroBase database via the HydroBase selection dialog. This approach may be phased out in the future in favor of the more generic datastore approach.
- Configure a HydroBase CDSS datastore using a configuration file and NO Open Database Connectivity (ODBC) Data Source Name (DSN). If the datastore name is configured as "HydroBase", this connection will supersede the "input type" when encountered in time series identifiers. The account will default to the CDSS service account. An example configuration file is shown in the HydroBase Datastore Configuration section below.
- o Configure a HydroBase CDSS datastore using a configuration file with an ODBC DSN. In this case, the ODBC DSN must be configured using a SQL Server driver with login cdss and password cdss%tools. An example configuration file is shown in the **HydroBase Datastore Configuration** section below.

• HBGuest user:

- Configure a Generic Database datastore using a configuration file and NO Open Database Connectivity (ODBC) Data Source Name (DSN). See the HydroBase Datastore Configuration section below). This approach may be needed if the ODBC DSN configuration (next item) results in errors, and the text configuration file may be more transparent than the ODBC DSN.
- Configure a HydroBase datastore using a configuration file with an ODBC DSN. In this case, the ODBC DSN must be configured using a SQL Server driver with login
 HBGuest and password 1HBGuest. See the example for the CDSS account in the
 HydroBase Datastore Configuration section below.

The State of Colorado's HydroBase database stores a variety of time series data. The time series conventions described here, in particular for time series identifiers, are consistent for major CDSS software components including TSTool, StateView/CWRAT, StateDMI, and StateMod GUI. This allows for consistent features and sharing of data between software tools.

The current database design splits time series into three main categories:

- 1. Data related to structures or administrative data maintained by the State of Colorado (e.g., diversions, reservoirs). Structure locations are typically identified using a water district identifier (WDID), consisting of a two-digit State of Colorado water district number and a trailing structure identifier (which in the past was four digits but has been increased to five or more digits to support longer identifiers). Although a single WDID identifier is used when identifying time series, the separate WD and ID fields are generally needed to find information in HydroBase.
- 2. Data for stations, consisting mainly of location information and time series (e.g., NOAA precipitation data, USGS streamflow). Station locations are typically identified using a station identifier from the data source. For example, stations can use a USGS identifier, a State of Colorado Satellite Monitoring System abbreviation, or other identifier.
- 3. Data recorded at locations that are not stations or structures. For example, Water Information Sheet (WIS) are daily spreadsheets used to administer water. Although WIS contain data values for structures an stations, the time series are extracted from database tables that are not directly associated with structure or station database tables. Other examples include Colorado and national agricultural crop statistics.

A structure or station may have more than one identifier depending on the number of agencies involved with data collection, etc. For example, a reservoir may have a State of Colorado WDID because it has water rights, a Bureau of Reclamation identifier, a US Geological Survey identifier, and a second State of Colorado identifier corresponding to a real-time data station. HydroBase collects data from many sources; however, the State has not attempted in all cases to cross-references the identifiers. For example, a streamflow station may have a partial time series record with a "USGS" data source and identifier and a partial time series record with a "DWR" (Division of Water Resources) data source and identifier – the user must recognize that this may be the same station, under different management at different times.

HydroBase is updated for release to the public approximately once per year, although internal updates may occur year-round. Time series are used with CDSS (Colorado's Decision Support Systems) applications and follow basic time series standards when used by TSTool and other software.

HydroBase and Standard Time Series Properties

The standard time series identifier format for HydroBase datastore time series is of the form:

Location.DataSource.DataType.Interval~DataStoreName

Due to the variety of data types, sources, and formats in HydroBase, time series properties can be set a number of ways. General guidelines are as follows:

- The location part of the time series identifier is set to a station or structure identifier, which is typically the identifier used by the managing agency. For example, USGS stream gages use the 8-digit USGS identifier and State of Colorado diversions use a7-character zero-padded structure WDID (water district identifier). Wells often use the latitude and longitude merged together (see additional comments in the wells section).
- The source part of the time series identifier corresponds to a data provider abbreviation. For example, if the current provider for a time series is the USGS, then the data source will be USGS. If the State of Colorado has at some point taken over maintenance of a station from the USGS, then the data source will be DWR. Individual data records may indicate a variety of data sources. The convention in HydroBase is to store the data records under the current data source, rather than force the user to query more than one time series and merge the time series. If, however, a station has moved, then separate time series typically will be available, likely under different identifiers. For this reason, the location of the station or structure is important in understanding historical records.
- The data type part of the time series identifier as much as possible uses the "measurement type" information in HydroBase or a readable and reasonable data type phrase. For example Precip is a measurement type for station data and DivTotal (diversion total) is a measurement type for diversion data. In some cases, especially with real-time data, the data type may not exactly match HydroBase. For example, HydroBase uses a measurement type RT_Rate for multiple stream related data types. TSTool uses a data type of Streamflow. The tables at the end of this appendix describe all available HydroBase data types and provides guidance for upgrading from old data types.
- Data intervals are set based on the tables that are being queried. In most cases, a regular interval like Day or Month is used. Irregular is used for real-time data because there currently is no way to know without doubt what the regular data interval is (e.g., 15MIN). Data that are measured infrequently (e.g., reservoir field measurements) typically are stored as a regular interval time series with interval Day. This allows more flexibility in data processing and filling.
- In older versions of TSTool, the scenario part of the identifier (after the interval) was sometimes used to supplement the data type information. For example, real-time flow data in the database has a number of attributes (Streamflow, RT_Rate, DISCHRG) that cannot easily fit into the standard time series identifier. The current version of TSTool uses datatype-subdatatype where necessary and generally does not use the scenario for normal time series identifiers (WIS time series are an exception) and this field is being reserved to possibly indicate historical data, filled data, etc.
- Units are set based on the database table definitions.
- Period of record is set based on the available database contents. Periods displayed when listing stations and time series typically are not determined by checking the data because this would require querying large amounts of data. Instead, periods are determined from summary information available in the database. In some cases, the period of record information is not saved at a precision sufficient to accurately represent the true period (e.g., the database may indicate data for years but not months). Therefore, the true period will only be available when time series data values are queried.
- Missing data typically are set to -999 in time series but are stored as nulls in the database. TSTool does allow NaN (not a number) to be used but -999 continues to be used to match legacy conventions.
- The input type of the time series identifier is set to the datastore name, which typically is HydroBase for a default connection. If multiple HydroBase connections are needed, the datastore configuration information is used to assign an appropriate name.

• The time scale for data (whether accumulated [ACCM], instantaneous [INST], or mean [MEAN]) is not automatically determined from the data type and interval but must be understood from the data type.

Diversion data may be retrieved from several tables in HydroBase, including daily and monthly detailed records, infrequent values, diversion comments, and currently in use values. The TSTool ReadHydroBase() command provides several options for handling data and the FillUsingDiversionComments() command can be used to fill with additional zero values. When using time series identifiers to read time series, the following defaults are used:

- Daily DivClass and DivTotal time series are filled using the carry-forward technique implemented by the State of Colorado. Missing irrigation years remain missing. Years with data are filled with zeros at the start and values are carried forward until another observation is found, or to the end of the irrigation year.
- Diversion comments and "currently in use" flag are NOT automatically applied. This default may change in the future but is retained for historical data processing reasons.

Limitations

HydroBase has the following limitations related to time series storage:

- The station and structure measurement types and time series tables defined in HydroBase do not always allow information to be determined from database records. Instead, some time series properties must be hard-coded based on the table design. For example, the <code>meas_type</code> table has a <code>MeanTemp</code>, <code>MaxTemp</code>, <code>MinTemp</code> types defined, but these refer primarily to the separate daily tables for such data. The <code>monthly_temp</code> table includes <code>avg_max_t</code>, <code>avg_min_t</code>, and <code>mean_t</code> fields that do not correspond one-to-one with <code>meas_type</code> values. Therefore, applications like TSTool use data types that are not specifically defined as strings in HydroBase, which have consequently been hard-coded. This is an issue with station and structure time series.
- Real-time data types in HydroBase do not directly translate to time series data types used in TSTool. An effort has been made to be as consistent as possible while using data types that can be understood by users.
- Data units are not defined consistently in tables. Some tables have a units string and others do not and the units abbreviations are not always consistent (units of "A" are often used for acre-feet and "C" for CFS). A master units table is not used in HydroBase to enforce data units consistency throughout the database.
- The time scale for time series (whether accumulated, instantaneous, or mean) is not automatically determined from the data type and interval. Users much understand how to interpret the data, in particular when changing the data interval.

Datastore Configuration Files

A datastore is configured by enabling a HydroBase datastore in the main *TSTool.cfg* configuration file and creating a datastore configuration file for each connection. Configurations are processed at software startup to enable datastores. An example of the TSTool configuration file is shown below. Multiple datastores can be defined using the [DataStore:DataStoreName] syntax. Properties for each datastore are specified in an accompanying configuration file described after the following example.

```
# Configuration file for TSTool
[TSTool]

HydroBaseEnabled = true

# Startup datastores (note that datastore name in config file takes precedence)

# Datastore for Colorado's HydroBase database, CDSS account

# (active if HydroBaseEnabled=true above)
[DataStore:HydroBase2012]
ConfigFile = "HydroBase2012.cfg"

# Datastore for Colorado's HydroBase database, HBGuest account

# (active if HydroBaseEnabled=true above)
[DataStore:HydroBase-HBGuest]
ConfigFile = "HydroBase-HBGuest.cfg"
```

TSTool Configuration File with HydroBase Properties

HydroBase CDSS Account (No ODBC DSN)

The following illustrates the HydroBase datastore configuration file format for the CDSS account NOT using an ODBC DSN. The configuration file is located in the same folder as the TSTool configuration file and configures a datastore named "HydroBase". The default "cdss" service account is used for authentication and allows read-only access to the database.

```
# Configuration information for HydroBase database datastore, CDSS account.
# The user will see the following when interacting with the datastore:
# Name - datastore identifier used in applications, for example as the
      input type information for time series identifiers (usually a short string)
# Description - datastore description for reports and user interfaces (short phrase)
# The following are needed to make database connections in the software
# Type - must be HydroBaseDataStore
# DatabaseEngine - the database software (SqlServer is current standard)
# DatabaseServer - IP or string address for database server, with instance name
                   (e.g., "localhost\CDSS" can be used for local computer). Omitting
                  the instance name will result in default port numbers being tried
#
                  until one works.
# DatabaseName - database name used by the server (e.g., HydroBase CO 20120722)
# SystemLogin - service account login (omit for default)
# SystemPassword - service account password (omit for default)
# Enabled - if True then datastore will be enabled when software starts, False to disable
Type = "HydroBaseDataStore"
Name = "HydroBase"
Description = "HydroBase Datastore"
DatabaseEngine = "SqlServer"
# Local SQL Server Express installation...
```

```
DatabaseServer = "amazon\CDSS"
DatabaseName = "HydroBase_CO_20120722"
```

HydroBase Datastore Configuration File for Default CDSS Account (no ODBC DSN)

HydroBase CDSS Account Using ODBC DSN

The following illustrates the HydroBase datastore configuration file format for the CDSS account using an ODBC DSN. The configuration file is located in the same folder as the TSTool configuration file and configures a datastore named "HydroBase-DSN". The ODBC DSN must have been configured using SQL Server authentication and the cdss account information. This approach can be problematic if the ODBC driver, authentication, method, or other SQL Server configuration information is in error.

```
# Configuration information for HydroBase database datastore, CDSS account, using ODBC DSN.
# The user will see the following when interacting with the datastore:
# Name - datastore identifier used in applications, for example as the
     input type information for time series identifiers (usually a short string)
# Description - datastore description for reports and user interfaces (short phrase)
# The following are needed to make database connections in the software
# Type - must be GenericDatabaseDataStore
# DatabaseEngine - the database software (SglServer is current standard)
# OdbcName - the Open Database Connectivity Data Source Name (ODBC DSN), configured
      in Windows Control Panel
# Enabled - if True then datastore will be configured when software starts, False to disable
Enabled = True
Type = "GenericDatabaseDataStore"
Name = "HydroBase-DSN"
Description = "HydroBase Datastore using DSN"
DatabaseEngine = "SqlServer"
OdbcName = "HydroBase-DSN"
```

HydroBase Datastore Configuration File for CDSS Account Using ODBC DSN

HydroBase HBGuest Account using Generic Database Datastore (No ODBC DSN)

The following illustrates the Generic Database datastore configuration file format for the HBGuest account NOT using an ODBC DSN (see also the **Generic Database Datastore** appendix). The configuration file is located in the same folder as the TSTool configuration file and configures a datastore named "HydroBase-HBGuest". The "HBGuest" service account is used for authentication and allows read-only access to the database.

```
# Configuration information for HydroBase database HBGuest datastore,
# using generic database datastore.
#
# The user will see the following when interacting with the datastore:
#
# Name - datastore identifier used in applications, for example as the
# input type information for time series identifiers (usually a short string)
# Description - datastore description for reports and user interfaces (short phrase)
#
# The following are needed to make database connections in the software
#
# Type - must be GenericDatabaseDataStore
```

```
# DatabaseEngine - the database software (SqlServer is current standard)
# DatabaseServer - IP or string address for database server, with instance name
                  (e.g., "localhost\CDSS" can be used for local computer)
# DatabaseName - database name used by the server (e.g., HydroBase CO 20120722)
# SystemLogin - service account login (specify for HBGuest account)
# SystemPassword - service account password (specify for HBGuest account)
Enabled = True
Type = "GenericDatabaseDataStore"
Name = "HydroBase-HBGuest"
Description = "HydroBase HBGuest Datastore"
DatabaseEngine = "SqlServer"
# Local SQL Server Express installation...
DatabaseServer = "localhost\CDSS"
DatabaseName = "HydroBase_CO_20121126"
# Specify HBGuest login...
SystemLogin = "HBGuest"
SystemPassword = "1HBGuest"
```

Generic Database Datastore Configuration File for HydroBase HBGuest Account

Troubleshooting

The following table lists errors that may result from connecting to or using HydroBase, and potential solutions to address the errors.

Errors and Possible Solutions

Error	Possible solutions
A HydroBase	1. Verify that the configuration information specified in the HydroBase
datastore	datastore configuration file is correct by using another tool to connect to
configuration	the database:
generates errors.	a. Sequel Server Management Studio (SSMS)
	b. Create an Open Database Connectivity Data Source Name (ODBC DSN).
	c. Use a database tools such as SQuirreL (see http://squirrel-sql.sourceforge.net/).
	2. If the DatabaseServer has been specified with an instance name (e.g.,
	"ServerName\CDSS", then the server computer (even if the local
	computer) must be running the SQL Server Browser process. Otherwise,
	the port number cannot be determined from the instance name. The SQL
	Server Browser process is started as a service under <i>Windows Control</i>
	Panel Administrative ToolsServices. Locate the Sql Server
	Browser entry, edit its properties, and set the Startup type to Automatic
	or Manual and press Start to start the service. You must have
	administrator privileges to make this change.
A specific	Time series in HydroBase are associated with the data source (e.g., USGS).
requested time	These data source abbreviations or their handling by software may have
series is not	changed over time and a data source in a time series identifier may not be
returned from the	valid. Current software requires the data source for HydroBase time series, if a
HydroBase	data source is used with the data type in HydroBase. Try interactively
database.	querying the time series to see if the data source has changed.
Bulk time series	1. By default all data are returned. However, a filter or previous command
queries do not	may have specified limiting criteria, such as the input period fo r the query.

Error	Possible solutions
returned data from	2. Verify that the database includes the water districts of interest using the
HydroBase.	FilePropertiesHydroBase Information menu. HydroBase is
	distributed for the State of Colorado and water divisions and the version
	being used may be for a division. Subsets of the entire state were
	distributed in older versions of the database.

Available Time Series by Data Type Categories

The following tables present a summary of time series identifier fields for the HydroBase data types. Data sources may be added and/or removed with data updates. Data types are listed by major group and are alphabetized by the data type description within the group. The time scale is provided to facilitate data use, in particular when changing the time interval.

HydroBase Time Series Types and Standard Time Series Identifier Fields Agricultural Crop and Livestock Data

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Agricultural/ CASS	Colorado Agricultural Statistics Service crop area harvested	County Name	CASS	CropAreaHarvest ed-Commodity_ Practice Commodity and practice are from available values in HydroBase.	Year INST	See NASS data for orchards, pasture, and vegetables. Perennial crops usually have only harvested value.
	CASS area planted	County Name	CASS	CropAreaPlanted -Commodity_ Practice Commodity and practice are from available values in HydroBase.	Year INST	Annual crops should have planted value but use maximum of planted and harvested if necessary.
	CASS livestock head	County Name	CASS	LivestockHead-Commodity_Type Commodity and type are from available values in HydroBase.	Year INST	For each commodity (e.g., sheep), multiple types (e.g. sheep at various maturity levels).
Agricultural/ GIS	CDSS irrigated lands assessment result. See also Diversion Comments below.	WDID	CDSSGIS	CropAreaAllIrri gation-CropType CropAreaDrip- CropType CropAreaFlood- CropType CropAreaFurrow- CropType CropAreaSprinkl er-CropType CropType is taken from available values in HydroBase.	Year INST	Data are only available for years where DSS projects or data refreshes have occurred. Partial data for intermediate years may be available in spatial data layer attributes but not HydroBase. Data are available for lands served by surface water structures, listed by crop/year/irrigation type.
Agricultural/ NASS	CropArea	County Name	NASS	CropArea- Commodity Commodity is taken from available values in HydroBase.	Year INST	See CASS data where available. NASS does not distinguish between planted and harvested. NASS data are useful for orchards, pasture, and vegetables, which may not be reported in CASS.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Climate Data) Climate Group Table 1 of 2

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Climate	Evaporation (Pan)	Station ID	NOAA	EvapPan	Day ACCM, Month ACCM	
				Old (obsolete) data type was EPAN.	HOITEII ACCH	
	Frost Dates (derived from temperatures)	Station ID	COAGM, NOAA	FrostDateL28S, FrostDateL32S, FrostDateF28F, FrostDateF32F Old (obsolete) data type was FrostDate or FrostDates.	Year INST	Time series in software are the Julian day of the year (1-366) to allow graphing, filling, and manipulation.
	Precipitation	Station ID	COAGM, NOAA	Precip Old (obsolete) data type was PTPX.	Day ACCM, Month ACCM, Irregular ACCM	Irregular data are real-time increments.
	Snow (accumulation on ground during interval).	Station ID	NOAA	Snow Old (obsolete) data type was SNOG.	Day ACCM, Month ACCM	
	Snow course depth and snow water equivalent	Station ID	scs	SnowCourseDepth, SnowCourseSWE Old (obsolete) data type was SnowCrse, SNWE.	Day INST	Values are recorded on a day, with one or more times a month.
	Solar radiation	Station ID	COAGM	Solar Old (obsolete) data type was RADS.	Day ACCM	
	Temperature (instantaneous)	Station ID	various	Temp	Irregular INST	
	Temperature (maximum)	Station ID	COAGM, NOAA	TempMax Old (obsolete) data type was MaxTemp, TAMN.	Day INST	
	Temperature (mean of maximum daily values)	Station ID	COAGM, NOAA	TempMeanMax Old (obsolete) data type was MaxTemp, TAMX with monthly interval.	Month MEAN	
	Temperature (mean)	Station ID	COAGM, NOAA	TempMean Old (obsolete) data type was MeanTemp, TAVG.	Month MEAN	
	Temperature (minimum)	Station ID	COAGM, NOAA	TempMin Old (obsolete) data type was MinTemp, TAMN.	Day INST	
	Temperature (mean of minimum daily values)	Station ID	COAGM, NOAA	TempMeanMin Old (obsolete) data type was MinTemp, TAMN with monthly interval.	Month MEAN	

HydroBase Time Series Types and Standard Time Series Identifier Fields (Climate Data) Climate Group Table 2 of 2

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Climate	Vapor pressure (mean daily)	StationID	COAGM	Old (obsolete) data type was VP, MVP.	Day MEAN	
	Wind run	Station ID	AGRO, COAGM	Wind Old (obsolete) data type was UDIS.	Day ACCM	

HydroBase Time Series Types and Standard Time Series Identifier Fields (Demographic Data)

Demographic data are related to human population. See the Agricultural Data above for livestock population.

Data Group	Data Type Description	Location	Data Source	Data Type(s)	Available Intervals and Time Scale	Comments
Demographics	Human population (persons)	Area_type-Area_name The type indicates whether a county, municipality, state, etc. The name agrees with the type. The combination defines a unique location.	This could be assumed from the Pop_type part of the data type; however, the data source is not readily available in HydroBase.	HumanPopulat ion- Pop_type The population type is Census, Estimated, etc.	Year INST	See CDSS documents for information on how population estimates are determined.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Diversion Data)

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Diversion May include records for reservoir and well structures, as per State of Colorado administration practices. See also reservoir data.	Diversion Class (showing water color)	WDID	DWR	DivClass- SFUT Old (obsolete) data type was DQME, Div, or Diversion.	Day MEAN, Month INST or ACCM, Year INST or ACCM	SFUT is encoded as: S:s F:f U:u T:t s = source f = from u = use t = type Annual values are for irrigation year (Nov-Oct).
	Diversion Comment (the acreage for a diversion and string data flag indicating whether a structure irrigated in a year)	WDID	DWR	DivComment	Year INST or ACCM	The numerical time series value is set to the acreage for the year. The data quality flag is set to the HydroBase diversion_comment. not_used flag. Therefore, this time series can be used to extract total acreage for a structure and determine if diversions should be zero for a year. Annual values are for irrigation year (Nov-Oct).
	Diversion Total (sum of all DivClass records for a structure).	WDID	DWR	Old (obsolete) data type was DQME, Div, or Diversion.	Day MEAN, Month INST or ACCM, Year INST or ACCM	Annual values are for irrigation (Nov-Oct) year.

The above table summarizes how diversion records are available as time series. However, to determine a complete diversion time series, it is necessary to understand the various ways that diversion records can be stored. See also the **State of Colorado's Water Commissioner Manual**.

Raw data observations for a diversion structure are stored as one or more of the following forms in HydroBase:

- Daily water class time series. These data are recorded using irrigation year (November to October). If one or more values have been entered in a month, then HydroBase will include a full month of data. Days at the beginning of the irrigation year that have no observed values at the start of the year should be considered to be zero, regardless of values found in previous irrigation years. Once an observation occurs, then days within the month where an observation was not recorded are set to the last observed value. Therefore, if an irrigation year contains at least one value, that irrigation year will have at least one month of values (with no missing in the month). To preserve space in HydroBase, months with no observations are not included in the daily data in the database. If a year has no observation, then no data are available in HydroBase for the year and a determination of whether the data values should be zero or other must be determined using other data (see below) or engineering judgment. TSTool and StateView by default implement the carry-forward procedure within irrigation years.
- Diversion comments. Diversion comments may be included for an irrigation year. The not_used flag indicates if a diversion was not used in a year. If this is the case, then daily diversion records should not be available and a zero value can be assumed for the water year. TSTool and StateView DO NOT by default use diversion comments when providing daily or monthly time series.
- Infrequent water class. Infrequent water class values can be entered as an annual value for the irrigation year, or as a monthly value. The data can be accessed as time series in TSTool, although no specific capabilities have been implemented to supplement the daily or monthly time series.

Processed (derived) data records are created as follows:

- Daily total diversion. Daily water class values are accumulated to daily total records. Similar to the daily water class, any month that has at least one value will result in a month with no missing data. To preserve space in HydroBase, only months that include an observation are included in HydroBase. Other months in the same irrigation year should be carried forward. Irrigation years with no observation have no records in HydroBase and a determination of whether the data values should be zero or other must be made using other data (see below) or engineering judgment. TSTool and StateView by default implement the carry-forward procedure within irrigation years.
- Monthly water class. Monthly water class is computed by converting the daily water class values (average CFS) to ACFT for each day of the month, and adding the values. Because of the way that daily data are treated, a month will either have all daily values or none. A month with no data will have its value set to missing in the database. Full irrigation years with no observation will result in a full year of missing values, and a determination of whether the data values should be zero or other must be determined using other data (see below) or engineering judgment. Unlike daily data, monthly diversion records are included in HydroBase for the full data period. Full years of missing values may be included in the database.
- Monthly total diversion. This is derived using the same procedure as monthly water class; however, the daily total diversion is used as input.
- Infrequent data are not considered when producing the monthly total time series.

Therefore, to determine a complete time series, the following must be performed, using TSTool or other software:

Daily time series:

- 1. Read the daily time series from HydroBase. The default in TSTool and StateView is now to carry forward daily diversion time series within the irrigation year.
- 2. Utilize the diversion comments to set additional years of data to zero. Using diversion comments is an option with TSTool and StateDMI time series read commands.
- 3. For years with no data, use an appropriate fill technique. If it is known that the ditch did not operate, then zeros should be used. If it is known that the ditch did operate, use historical averages or some other method to fill the data.
- 4. HydroBase infrequent diversions could be used to supplement the data, but currently there is no software to help users with this process.

Monthly time series:

- 1. Read the monthly time series from HydroBase. Any irrigation year with at least one daily observation results in 12 monthly time series values.
- 2. Utilize the diversion comments to set additional years of data to zero. Using diversion comments is an option with TSTool and StateDMI time series read commands.
- 3. For years with no data, use an appropriate fill technique. If it is known that the ditch did not operate, then zeros should be used. If it is known that the ditch did operate, use historical averages or some other method to fill the data.
- 4. HydroBase infrequent diversions could be used to supplement the data, but currently there is no software to help users with this process.

Yearly time series:

1. Infrequent time series can be read by TSTool and can supplement the above data. However, currently there is no software to help users with this process. General TSTool commands must be used as appropriate.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Hardware Data)

Data Group	Data Type Description	Location	Data Source	Data Type(s)	Available Intervals and Time Scale	Comments
Hardware	Battery voltage	Station ID	DWR	Battery	Irregular INST	Limited data are available. This data type allows remote system maintenance checks.

Hardware data types are not commonly available have been implemented as a test and to allow for greater future use.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Reservoir Data) Reservoir Group Table 1 of 2

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Reservoir	Field Measurements	WDID	DWR, other	ResMeasElev, ResMeasEvap, ResMeasFill, ResMeas Release, ResMeas Storage Old (obsolete) data type was RSTO.	Day INST, Day ACCM, Day ACCM, Day ACCM, Day ACCM	Reservoir measurements are often recorded at the beginning or end of the month.
	Pool Elevation	Station ID or State of CO Abbrev.	DWR, other	PoolElev	Irregular INST	Real-time data for reservoirs are recorded using a station abbreviation that does not match a WDID.
	Release Class (showing water color)	WDID	DWR	RelClass- SFUT	Day MEAN, Month INST or ACCM, Year INST or ACCM	SFUT is encoded as: S:s F:f U:u T:t s = source f = from u = use t = type Annual values are for irrigation year (Nov-Oct).
	Release Comment (the acreage for a release and string data flag)	WDID	DWR	RelComment	Year INST or ACCM	See DivComment comments. Sometimes acreage is associated with reservoirs. Annual values are for irrigation year (Nov-Oct).
	Release Total (sum of all RelClass records for a structure).	WDID	DWR	RelTotal	Day MEAN, Month INST or ACCM, Year INST or ACCM	Annual values are for irrigation year (Nov – Oct).

HydroBase Time Series Types and Standard Time Series Identifier Fields (Reservoir Data) Reservoir Group Table 2 of 2

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Reservoir	Release (instantaneous)	Station ID	DWR, other	Release	Irregular INST	Real-time data for reservoirs are recorded using a station abbreviation that does not match a WDID.
	Reservoir Storage (end of month).	WDID	USBR, DWR, other	Old (obsolete) data type was RSTO.	Month INST	Few time series are available.
	Reservoir Storage (end of year).	WDID	USBR, DWR, other	ResEOY	Year INST	From annual_res table. Annual value is for irrigation year (Nov-Oct).
	Storage (instantaneous)	Station ID or State of CO Abbrev.	DWR, other	Storage	Irregular INST	Real-time data for reservoirs are recorded using a station abbreviation that does not match a WDID.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Stream Data)

Data Group	Data Type Description	Location	Data Source	Data Type	Available Intervals and Time Scale	Comments
Stream	Natural Flow	Station ID	USBR	Old (obsolete) data type was Nat flow, NQME	Month INST or ACCM	
	Stage	Station ID	DWR, other	Stage	Irregular INST	Real-time data.
	Streamflow	DWR Abbrev. or USGS station ID	DWR, USGS, other	Old (obsolete) daily, monthly data type was QME. Old real-time data type used RT_rate and scenario DISCHRG or other VAXfield to indicate channel.	Day MEAN, Month INST or ACCM, Irregular INST	Real-time data use Irregular time interval.
	Streamflow (maximum of daily mean)	Station ID	DWR, USGS	Old (obsolete) data type was Maxq, Maxflow.	Month INST	
	Streamflow (minimum of daily mean)	Station ID	DWR, USGS	Old (obsolete) data type was Minq, Minflow.	Month INST	
	Water temperature (instantaneous)	Station ID, State of CO Abbrev.	DWR, other	WatTemp	Irregular INST	Real-time data, using identifier that does not match USGS or other identifier for historical data.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Water Information Sheet Data)

Data Group	Data Type Description	Location	Data Source	Data Type	Available Interval and Time Scale	Comments
WIS	Water Information Sheet (WIS) cell values, over time	WIS row identifier. For example, structures have an identifier wdid:NNNN NNN, where the leading "wdid:" is a literal string and the following information is the actual WDID. Similarly, stations start with "stat:", followed by a station ID; confluences with "conf:", followed by the HydroBase wd_water numbers for the tributary and the larger stream; other row types with "othr:", followed by a sequential number in the WIS.	DWR	Data types match the WIS columns, as follows: WISPointFlow, WISNaturalFlow, WISDeliveryFlow, WISGainLoss, WISRelease, WISPriorityDiversion, WISDeliveryDiversion, WISTribNaturalFlow, WISTribDeliveryFlow, WISDryRiver (not currently implemented - may be implemented as a data flag in the future).	Day MEAN	The scenario part of the time series identifier is set to the sheet name. Over time, WIS with a particular sheet name may be modified in format. The combination of sheet name and row identifier can be used to find data. The time series description is set to the row label. Data values are as stored for the WIS, which reflect the gain method used when the sheet was stored.

HydroBase Time Series Types and Standard Time Series Identifier Fields (Well Data)

Data Group	Data Type Description	Location	Data Source*	Data Type	Available Intervals and Time Scale	Comments
Well	Well level (elevation and depth)	Location identifier, based on the current data source. For example, if the data source is USGS, the location identifier will be the USGS identifier.	BJORKLUND CH2MHILL CSU CWSD DWR FOX HALAPASKA HILLIER MCCONAGHY NELSON ROBSON ROBSONBANT SCHNEIDER SEO SMITH SOUTHMETRO SPDSS USGS USGS_NAWQA WILSON *as of 2005- 06-16	WellLevel (phasing out in favor of WellLevelElev), WellLevelDepth, WellLevelElev	Day INST, Irregular INST	Daily data are historical measurements, often at the ends of a month. A well may have multiple identifiers. However, the identifier presented in TSTool is that corresponding to the primary data source. See information below this table. Irregular data are real-time using state station abbreviations, which do not match the identifier for historical data.

The vw_CDSS_GroundwaterWellsGroundwaterWellsMeasType view in HydroBase contains the metadata for well level data. Well identifiers are used in TSTool time series identifiers as follows:

- 1. If the view identifier column has a value, the value is used for the well identifier. Typically this is the identifier for the primary data provider.
- 2. If the WD ID values are available, they are used.
- 3. If the latitude and longitude are available, the location identifier is set to LL:LatLong, where latitude is format DDMMSS and longitude is DDDMMSS (positive value). The conversion of decimal degrees to degrees, minutes, and seconds truncates the remainder on the seconds. Subsequent reverse lookups of the well occur by querying a box around the location from the identifier and then regenerating the LL: identifier to find a match. This may result in duplicate identifiers if wells are very close together, and will generate an error. The use of the temporary identifier can be minimized by reviewing original data and ensuring that a valid identifier column value is defined in HydroBase.
- 4. If none of the above methods can be used to assign a location identifier to the time series, an error will result.

HydroBase Datastore					
	This page is intentionally blank.				