
Command Reference: ReadDelftFewsPiXml()

Read all time series from a Delft FEWS PI XML File

Version 11.08.01, 2016-02-26

The ReadDelftFewsPiXml() command reads all the time series in a Delft FEWS PI XML file. See the **Delft FEWS Input Type Appendix** for information about the file format.

The following dialog is used to edit the command and illustrates the command syntax.



toro

ReadDelftFewsPiXml() Command Editor Showing Time Series Parameters

ı	Time Series	Ensembles					
	Ensembles are created by grouping time series with matching <ensembleid> property in the PI XML file.</ensembleid>						
	The TSTool EnsembleID will default to the locationId_DataType_ensembleId (DataType can be specified as parameter).						
	Relevant elements from the PI XML file are saved as properties on the ensemble and can be accessed with \${tsensemble:property}.						
	Important: TSTool EnsembleID can be different from the ensembleId value (property names are case-specific).						
	Er	nsemble ID:	Ensemble-%L-%T	Optional - ensemble ID (default=locationId_DataType_ensembleId).			
	Enser	mble name:		Optional - ensemble name (default=EnsembleID).			

ReadDelftFewsPiXml_Ensemble

ReadDelftFewsPiXml() Command Editor Showing Ensemble Parameters

The command syntax is as follows:

ReadDelftFewsPiXml(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
InputFile	The name of the PI XML input file to read. Global property values can be used with the syntax \${PropertyName}. The file can be a *.xml, *.zip or *.gz file with single compressed file.	None – must be specified.
Output	 Indicate the output to be generated: TimeSeries – individual time series (even if in ensemble) TimeSeriesAndEnsembles – individual time series and ensemble 	TimeSeries AndEnsembles
TimeZone Offset	The desired time zone offset for output. 0=GMT, 7=US Mountain Standard Time.	Use file time zone.
TimeZone	Time zone string to assign to output date/times, for example MST. No check is performed on the validity of the value. The time zone should agree with the result of applying TimeZoneOffset.	No time zone is assigned.
InputStart	Starting date/time to read data, in precision consistent with data. Specify as a date/time string or a processor \${Property}.	Read all data.
InputEnd	Ending date/time to read data, in precision consistent with data. Specify as a date/time string or a processor \${Property}.	Read all data.
DataSource	Data source to use for time series identifier, for example organization that is running FEWS. Can specify with \${ts:Property} and time series % specifiers.	FEWS
DataType	Data type to use for time series identifier, useful because default can be long and may contain special characters. Can specify with \${ts:Property} and time series % specifiers.	<pre><paramerid> element from PI XML file</paramerid></pre>
Description	Time series description. Can specify with \${ts:Property} and time series % specifiers.	<pre><stationname> element from PI XML file</stationname></pre>
Read24Hour AsDay	If True, read 24Hour interval time series as Day. Hour 00 values are shifted to the previous day.	False
Read24Hour AsDayCutoff	If the value of the 24Hour time series is <= this value, then the day will be decremented in the output time series. This is necessary because hourly data may not exactly line up with days (hour 0) and it may be appropriate to shift to the previous day depending on the data type.	0
Alias	The alias to assign to the time series, as a literal string or using the special formatting characters listed by the	No alias is assigned.

Parameter	Description	Default
	command editor. The alias is a short identifier used by	
	other commands to locate time series for processing, as	
	an alternative to the time series identifier (TSID).	
EnsembleID	Ensemble identifier to assign to output. Can specify	<locationid></locationid>
	with \${ts:Property} and time series % specifiers.	_DataType_
		<pre><ensembleid></ensembleid></pre>
EnsembleName	Ensemble name to assign to output. Can specify with	Value of
	\${ts:Property} and time series % specifiers.	EnsembleID

ReadDelftFewsPiXml()	Command

TSTool Documentation

This page is intentionally blank.