
## Command Reference: readMODSIM()

## Read all time series from a MODSIM output file

Version 06.10.08, 2005-09-22, Color, Acrobat Distiller

The readMODSIM() command reads into memory all the time series in a MODSIM output file (see the **MODSIM Input Type Appendix**). The actual reading occurs as the commands are being processed. Therefore, if any other commands reference the MODSIM time series, the time series identifiers must be specified manually (they are not available to list in dialogs like other time series specified with identifiers) or use wildcards in identifiers. The following dialog is used to edit the command and illustrates the syntax for the command. Use the TS Alias = readMODSIM() command to read a single time series from a MODSIM file.



readMODSIM() Command Editor

readMODSIM

The command syntax is as follows:

readMODSIM(InputFile)

## **Command Parameters**

Parameter	Description	Default
InputFile	The name of the MODSIM file to read,	None – must be specified.
	surrounded by double quotes. The path	
	to the file can be absolute or relative to	
	the working directory. The <b>Browse</b>	
	button can be used to select the file to	
	read (if a relative path is desired, remove	
	the leading path after the select).	

A sample commands file is as follows:

readMODSIM("..\..\Data\_Modsim\CALIB42.GW")

readMODSIM() Command		TSTool Documentation
	This page is intentionally blank.	