Command Reference: TS Alias = readNDFD()

Read a time series from the NWS National Digital Forecast Database (NDFD)

Version 06.14.00, 2006-05-09, Color, Acrobat Distille

The TS Alias = readNDFD() command reads a single time series from the NWS NDFD data server (see the **NDFD Input Type Appendix**) and assigns an alias to the result.

The command syntax is as follows:

TS Alias = readNDFD(param=value,...)

Command Parameters

Parameter	Description	Default
Alias	Alias for the new time series that is read from	None – must be
	the NDFD, which can be used instead of the	specified.
	TSID by other commands.	
TSID	The time series identifier used to query	None – must be
	specific data from the NDFD data server.	specified.
NewUnits	The new units for the time series. The data	Do not convert the
	values will be converted to these units.	units.
InputStart	The start of the period to read – specify if the	Use the global input
	read period should be different from the	period or if not
	global query period. If the TSID states that	specified read from the
	this is a daily average data timeseries, specify	earliest date in the
	a start date not a start date/time.	database.
InputEnd	The end of the period to read – specify if the	Use the global input
	read period should be different from the	period or if not
	global query period. If the TSID states that	specified read to the
	this is a daily average data timeseries, specify	last data in the
	the number of days to read otherwise specify	database.
	an end date/time.	

A sample commands file to read all available 6 hour forecast qpf data is as follows:

```
TS precip = readNDFD(TSID="400120_1043012.NDFD.qpf-inst.6Hour~NDFD")
```

A sample commands file to read 6 hour qpf data for a specific period, and convert units to MM, is as follows:

```
TS precip = readNDFD(TSID="400120_1043012.NDFD.qpf-
inst.6Hour~NDFD", NewUnits="MM",
InputStart="2006-05-18 24", InputEnd="2006-05-22 24")
```

A sample commands file to read 24-hour average daily forecast of "12 Hour Probability of Precipitation" data as a time series is as follows:

```
TS precip = readNDFD(TSID="400120_1043012.NDFD.pop12-mean.Day~NDFD",
InputStart="2006-05-18", InputEnd="2006-05-25")
```

The following example commands file illustrates how to read two NWS forecast data time series from the NDFD server. The time series are upstream and downstream stations.

```
openNDFD()
TS ts_up = readNDFD(TSID="400120_1044218.NDFD.qpf-inst.6Hour~NDFD",
    InputStart="2006-05-18 24",InputEnd="2006-05-22 24")
TS ts_dn = readNDFD(TSID="400115_1042010.NDFD.qpf-inst.6Hour~NDFD",
    InputStart="2006-05-18 24",InputEnd="2006-05-22 24")
```