
Command Reference: readDateValue()

Read all time series from a DateValue File

Version 06.10.08, 2005-09-22, Color, Acrobat Distiller

The readDateValue() command reads all the time series in a DateValue file into memory (see the **DateValue Input Type Appendix**). The actual reading occurs as the commands are being processed. Therefore, if any other commands reference the DateValue time series, time series identifiers will need to be specified manually (they are not available to list in dialogs like other time series specified with identifiers) or use wildcards in identifiers.

The following dialog is used to edit the command and illustrates the syntax for the command. The path to the file can be absolute or relative to the working directory. The **Browse** button can be used to select the file to read (if a relative path is desired, delete the leading path after the select). Use the TS Alias = readDateValue() command to read a single time series from a DateValue file.



readDateValue() Command Editor

readDateValue

The command syntax is as follows:

readDateValue(InputFile)

Command Parameters

Parameter	Description	Default
InputFile	The name of the DateValue input file to	None – must be specified.
	read, surrounded by double quotes.	

A sample commands file is as follows:

readDateValue("..\..\Data_DateValue\08251500.DWR.Streamflow.IRREGULAR.dv")

readDateValue() Command		TSTool Documentation
readDate value() Command		131001 Documentation
	This page is intentionally blank.	