Preflight Fluids OFF Magnetos Fuel quantity **CHECK VISUALLY** Fuel sumps DRAIN Left wing, right wing, fuel strainer. Inspect for contamination. Fuel filler caps **SECURE** Engine oil level **CHECK** Minimum 6 quarts Cabin Pitot cover **REMOVE** POH **VERIFY PRESENT** Master ON Flaps **EXTEND CHECK QUANTITY** Fuel gauges Lights **CHECK** Tach time **RECORD** Pitot heat **TEST** OFF Master Fire extinguisher **SECURE** Control lock **REMOVE** Empennage Rudder gust lock REMOVE Control surfaces CHECK Freedom of movement and security Right **CHECK INFLATION** Main wheel tire Aileron CHECK Freedom of movement and security Nose Propeller, spinner **CHECK** For nicks and security Landing light **CHECK CLEAR** Air filter CHECK CLEAR Nosewheel & strut **CHECK INFLATED** Static source CHECK CLEAR Left CHECK INFLATION Main wheel tire

Preflight (continued)	·	
Fuel tank vent	CHECK CLEAR	
Pitot tube	CHECK CLEAR	
Stall warning TE		
Aileron CHEC		
Freedom of movement and security		
Final		
Flight Circle	DISPATCH	
Tach, Hobbs times	RECORD	
Baggage door LO		
Chocks	REMOVE	
Tie-downs REMO		

Securing	
Control lock	INSTALL
Tie-downs, chocks	APPLY
Vents, windows	CLOSE
Pitot cover	APPLY
Tach, Hobbs times	RECORD
Flight Circle	CHECK IN
Doors	LOCK

Speeds		
		KIAS
Best glide (V _G)		65
Best angle of climb (V _x)	Sea level 10,000 ft	64 62
Best rate of climb (V _Y)	Sea level 10,000 ft	78 68
Landing approach	Flaps up Flaps 40	60-70 55-65
Normal takeoff climb		70-80
Short-field takeoff climb	Flaps up Flaps 10	59 55
Normal enroute climb	Sea level 10,000 ft	80-90 70-80
Design maneuvering speed (V _A)	2300 lbs 1950 lbs 1600 lbs	97 89 80

Light Gun Signals	
Aircraft on the Ground	Aircraft in Flight
Cleared for takeoff	Cleared to land
Cleared for taxi 💻 🗖	steady green at the proper time)
STOP STOP	Give way to other aircraft and continue circling
Taxi clear of the runway in use 💻 💻	Airport unsafe, do not land
Return to starting point on airport \square	
Exercise extreme caution	Exercise extreme caution

Operating Checklists

Start			
Before Start			
Preflight inspection	COMPLETE		
Passenger briefing	COMPLETE		
Brakes	TEST and SET		
Seats, belts, harnesses	SECURE		
Fuel valve	BOTH		
Radios, electrical equipmer	nt OFF		
Circuit breakers	CHECK IN		
Beacon switch	ON		
Engine Sta	rt		
Mixture	RICH		
Carburetor heat	COLD		
Prime	AS REQUIRED		
Throttle	OPEN 1/8 INCH		
Master	ON		
Propeller area	CLEAR		
Ignition switch	START		
Release w	hen engine starts		
Oil pressure	CHECK		
If no pressure in 30 se			
Mixture	GROUND LEAN		
Before Tax	i		
Avionics	ON		
Headset	ON		
Flaps	RETRACT		
Weather	OBTAIN		
Altimeter	SET		
EFB Setup	AS DESIRED		
Navigation, landing lights	ON		

CHECK and SET
IF NEEDED
SET
CLOSED, LOCKED
FREE and CORRECT
вотн
RICH (below 3000 feet)
1700 RPM
CHECK
5 RPM, max diff. 50 RPM
neter CHECK
CHECK
TEST
TEST
GROUND LEAN
ADJUST

		_
Before Takeoff		
Radios	SET	٦
Instruments	SE1	
Takeoff briefing	COMPLETE	:
Beacon, navigation,	landing lights ON	ı
Carburetor heat	AS REQUIRED)
Flaps	0-10	,
Trim	TAKEOFF	:
Fuel valve	BOTH	ł
Fuel quantity	CHECK	
Mixture	RICH (below 3000 feet	J

Climb		
Airspeed	70-90) KIAS
Throttle		FULL
Mixture	RICH (lean above 3000) feet)

Cruise	
Power	2200-2700 RPM
	No more than 75% power
Trim	ADJUST
Mixture	LEAN (for max RPM)

Descent	
Mixture	RICH
Power	AS DESIRED
Carburetor heat	AS REQUIRED
	To prevent carburetor icing

Before Landin	g
Fuel valve	вотн
Mixture	RICH
Carburetor heat	ON
Apply fu	II heat before closing throttle
Airspeed	60-70 KIAS (flaps UP)
Flaps	AS DESIRED
Airspeed	55-65 KIAS (flaps DOWN)

FULL
COLD
20°
55 KIAS
RETRACT slowly

After Landing	
Flaps	UP
Caburetor heat	OFF
Mixture	GROUND LEAN

Shutdown	
Brakes	SET
Tach time	RECORD
Radios, electrical equipment	OFF
Mixture	CUT-OFF
Magnetos	OFF
Master	OFF

Version 1 PR 57

Engine Failures, Forced Landings

Engine Failure During Takeoff Run Throttle IDLE Brakes APPLY Flaps RETRACT Mixture CUT-OFF Magnetos OFF

Engine Failure Shortly After Takeoff Airspeed Flaps up: 65 KIAS Flaps down: 60 KIAS Mixture CUT-OFF Fuel valve OFF Magnetos OFF Flaps AS REQUIRED Master OFF

Engine Failure During Flight			
Airspeed	65 KIAS		
Carburetor heat	ON		
Fuel valve	ВОТН		
Mixture	RICH		
Magnetos	ВОТН		
	(START if prop stopped)		
Primer	IN and LOCKED		
Primer			

Forced Landing	With Engine Failure
Airspeed	Flaps up: 65 KIAS
	Flaps down: 60 KIAS
Mixture	CUT-OFF
Fuel valve	OFF
Magnetos	OFF
Flaps	AS REQUIRED
	40° recommended
Master	OFF
Doors UNLATCH	BEFORE TOUCHDOWN
Touchdown	SLIGHTLY TAIL LOW
Brakes	APPLY HEAVILY

Precau	tionary Lar	nding
Flaps		20°
Airspee	d	60 KIAS
Selected	d field	FLY OVER
	Note ter	rain/obstructions.
	Retract	flaps upon reaching
	a safe a	Ititude and airspeed.
Radios, electrical switches OFF		
Flaps	40	° (on final approach)
Airspee	d	60 KIAS
Master		OFF
Doors	UNLATCH BI	FORE TOUCHDOWN
Touchdo	wn	SLIGHTLY TAIL LOW
Magnet	os	OFF
Brakes		APPLY HEAVILY

Ditching			
Radio	MAYDAY on 121.5 MHz		
	Give location, intentions		
Heavy objects	SECURE or JETTISON		
Flaps	20°-40°		
Power 300 FT	MIN DESCENT AT 55 KIAS		
If no power	available, approach		
flaps up 65	KIAS or flaps 10° 60 KIAS		
Strong wind, he	-		
LAND INTO WIND			
Light wind, heavy swells: LAND PARALLEL TO SWELLS			
Doors	UNLATCH		
Touchdown	LEVEL ATTITUDE		
at established rate of descent			
Face CUSHIO	N at touchdown with coat		
Airplane	EVACUATE		
Life vests/raft	INFLATE		

Fires, Icing, Flat Tire, Electrical

Wing Fire Nav lights

Throttle

Cranking		CONTINUE
If engine starts:		
Power	1700 RPM for a	few minutes
Engine		SHUTDOWN
If engine fails to	start:	
Throttle		FULL OPEN
Mixture		CUT-OFF
Cranking	CONTINUE for	2-3 minutes
Fire extinguish	ner	OBTAIN
Master		OFF
Magnetos		OFF
Fuel valve		OFF
Fire		EXTINGUISH
	e extinguisher, s	
	lanket, or dirt. If	
	nove air filter if it	
	pect and repair da	9
before conduction	ng another flight.	

Engine Fire During Start On Ground

	Engine Fire in Flight		
	Mixture	CUT-OFF	
	Fuel valve	OFF	
	Master	OFF	
	Cabin heat & air	OFF	
(except overhead vent			
Airspeed 100			
	If fire is not extinguished, increase		
	glide speed to find an airspeed which		
	will provide an incombustible mixtur		
	Forced Landing With	EXECUTE	
	Engine Failure checklist		

Master	OFF
All other switches (except magnetos)	OFF
Vents/cabin air/heat	CLOSE
Fire extinguisher	USE
If fire appears out and electrical power	r is
necessary to continue flight:	
Master	ON
Circuit breakers	CHECK
(do not reset faulty	circuit)
Radio/electrical switches	ON
One at a time with delay after	
each until short circuit is lo	calized
Vents/cabin air/heat	OPEN
(when fire completely exting	uished)

Electrical Fire in Flight

Cabin Fire		
Master	OFF	
Vents/cabin air/heat	CLOSED	
	(to avoid drafts)	
Fire extinguisher	USE	
WARNING: After discharging extinguisher		
within a closed cabin, ventilate cabin		
Land ASAP, inspect for damage		

	Pitot heat	OFF	
	NOTE: Sideslip to keep flames away from		
	fuel tanks and cabin. Land ASAP using flaps		
	only as required.		
١.			
	Inadvertent Icing Encounter		
	Pitot heat	ON	
	Turn back or change altitude to obtain an		
	OAT less conducive to icing.		
	Cabin heat Fl	JLL ON	
	Defroster	OPEN	
	Cabin air A	ADJUST	
	Maximize defroster heat and	airflow	

OFF

Carburetor/air	filter icing	MONITOR	
Apply carb heat as required, lean mixture			
for maxim	um RPM if used	continuously	
Land	NE	AREST AIRPORT	
With	n very rapid ice	build-up, select	
suit	able off-airport	landing site	
With ≥ 1/4 incl	With $\geq 1/4$ inch ice on the leading edges,		
prepare for sig	nificantly highe	er stall speed	
Flaps	LE	AVE RETRACTED	
Open left window and scrape ice from			
windshield, if necessary for visibility			
Forward slip if necessary for visibility			
Approach speed 65-75 KIAS			
Depe	nding on level	of accumulation	
Landing	Perform	in level attitude	

Static Source Blocka	ige	
Alternate static source	valve	PULL ON
Airspeed	Use calib	oration table
	in POH s	ection 5

Static Source Blockag

Landing With a Flat Main Tire	
Approach	NORMAL
Touchdown	GOOD TIRE FIRST
Hold airplane off flat tire	as long as possible

Over-Voltage Light Illuminates				
Master	OFF (both sides)			
Master	ON			

Master	ON
If over-voltage light illur	ninates again:
Flight	TERMINATE ASAP

Ammeter S	hows Discharge	
Alternator		OFF
Nonessential electrical equipment		OFF
Flight	TERMINATE as soon as	practical