Ground Checklists and Information N73146

Preflight	
Fluid	
Magnetos	OFF
Fuel quantity	CHECK VISUALLY
Fuel sumps	DRAIN
Left wing, righ	nt wing, fuel strainer.
Inspect for co	ntamination.
Fuel filler caps	SECURE
Engine oil level	CHECK
	Minimum 6 quarts
Cabir	n .
Pitot cover	REMOVE
POH	VERIFY PRESENT
Master	ON
Flaps	EXTEND
Fuel gauges	CHECK QUANTITY
Lights	CHECK
Tach time	RECORD
Pitot heat	TEST
Master	OFF
Fire extinguisher	SECURE
Control lock	REMOVE
Empenn Dudder gust lask	REMOVE
Rudder gust lock Control surfaces	CHECK
	vement and security
Right	
Main wheel tire	CHECK INFLATION
Aileron	CHECK
	vement and security
Nose	
Propeller, spinner	CHECK
	or nicks and security
Landing light	CHECK CLEAR
Air filter	CHECK CLEAR
Nosewheel & strut	CHECK INFLATED
Static source	CHECK CLEAR
Left	
Main wheel tire	CHECK INFLATION
Fuel tank vent	CHECK CLEAR
Pitot tube	CHECK CLEAR
Stall warning	TEST
Aileron	CHECK
Freedom of mo	vement and security
Final	
Flight Circle	DISPATCH
Tach, Hobbs times	RECORD
Baggage door	
	LOCK
Chocks Tie-downs	REMOVE REMOVE

Securing	
Control lock	INSTALL
Tie-downs, chocks	APPLY
Vents, windows	CLOSE
Pitot cover	APPLY
Tach, Hobbs times	RECORD
Flight Circle	CHECK IN
Doors	LOCK

Operating Checklists

Start	
Before Start	
Preflight inspection	COMPLETE
Passenger briefing	COMPLETE
Brakes	TEST and SET
Seats, belts, harnesses	SECURE
Fuel valve	BOTH
Radios, electrical equipment	OFF
Circuit breakers	CHECK IN
Beacon switch	ON
Engine Start	
Mixture	RICH
Carburetor heat	COLD
Prime	AS REQUIRED
Throttle	OPEN 1/8 INCH
Master	ON
Propeller area	CLEAR
Ignition switch	START
Release whe	en engine starts
Oil pressure	CHECK
If no pressure in 30 seco	onds, shutdown
Mixture	GROUND LEAN
Before Taxi	
Avionics	ON
Headset	ON
Flaps	RETRACT
Weather	OBTAIN
Altimeter	SET
EFB Setup	AS DESIRED
Navigation, landing lights	ON

Run-up	
Instruments	CHECK and SET
VOR Check	IF NEEDED
Brakes	SET
Doors and windows	CLOSED, LOCKED
Flight controls	FREE and CORRECT
Fuel valve	ВОТН
Mixture	RICH (below 3000 feet)
Throttle	1700 RPM
Magnetos	CHECK
Max drop 12!	5 RPM, max diff. 50 RPM
Engine gauges, amm	eter CHECK
Vacuum gauge	CHECK
Carburetor heat	TEST
Idle	TEST
Mixture	GROUND LEAN
Throttle friction	ADJUST

SET
SET
COMPLETE
landing lights ON
AS REQUIRED
0-10°
TAKEOFF
вотн
CHECK
RICH (below 3000 feet)

Climb	
Airspeed	70-90 KIAS
Throttle	FULL
Mixture	RICH (lean above 3000 feet)
	`

Cruise	
Power	2200-2700 RPM
	No more than 75% power
Trim	ADIUST
Mixture	LEAN (for max RPM)

Descent	
Mixture	RICH
Power	AS DESIRED
Carburetor heat	AS REQUIRED
	To prevent carburetor icing

Before Landing	
Fuel valve	вотн
Mixture	RICH
Carburetor heat	ON
Apply full	heat before closing throttle
Airspeed	60-70 KIAS (flaps UP)
Flaps	AS DESIRED
Airspeed	55-65 KIAS (flaps DOWN)

Balked Landing	
Throttle	FULL
Carburetor heat	COLD
Flaps	20°
Airspeed	55 KIAS
Flaps	RETRACT slowly

After Landing	
Flaps	UP
Caburetor heat	OFF
Mixture	GROUND LEAN

Shutdown	
Brakes	SET
Tach time	RECORD
Radios, electrical equipment	OFF
Mixture	CUT-OFF
Magnetos	OFF
Master	OFF

Version 1 PR 49

Engine Failures, Forced Landings

Engine Failure During	Takeoff Run
Throttle	IDLE
Brakes	APPLY
Flaps	RETRACT
Mixture	CUT-OFF
Magnetos	OFF

Engine Failure Shortly After Takeoff	
Airspeed	Flaps up: 65 KIAS
	Flaps down: 60 KIAS
Mixture	CUT-OFF
Fuel valve	OFF
Magnetos	OFF
Flaps	AS REQUIRED
Master	OFF

Engine Failure During Flight		
Airspeed		65 KIAS
Carburetor hea	t	ON
Fuel valve		BOTH
Mixture		RICH
Magnetos	BOTH (START if)	prop stopped)
Primer	IN	and LOCKED

Forced Land	ding With Engine Failure
Airspeed	Flaps up: 65 KIAS
	Flaps down: 60 KIAS
Mixture	CUT-OFF
Fuel valve	OFF
Magnetos	OFF
Flaps	AS REQUIRED
	40° recommended
Master	OFF
Doors	UNLATCH BEFORE TOUCHDOWN
Touchdown	SLIGHTLY TAIL LOW
Brakes	APPLY HEAVILY

Precaution	ary Landing
Flaps	20°
Airspeed	60 KIAS
Selected field	fly over
Note terra	in/obstructions. Retract flaps
upon reac	hing a safe altitude and airspeed.
Radios, elect	rical switches OFF
Flaps	40° (on final approach)
Airspeed	60 KIAS
Master	OFF
Doors	UNLATCH BEFORE TOUCHDOWN
Touchdown	SLIGHTLY TAIL LOW
Magnetos	OFF
Brakes	APPLY HEAVILY

DIAKES		ALLETILAVILI
Ditching		
Radio		MAYDAY on 121.5 MHz
		Give location, intentions
Heavy obje	cts	SECURE or JETTISON
Flaps		20°-40°
Power	300 FT/N	MIN DESCENT AT 55 KIAS
lf	no power a	available, approach
fla	aps up 65 l	KIAS or flaps 10° 60 KIAS
Strong wine	d, heavy se	eas: LAND INTO WIND
Light wind,	heavy swe	ells:
LAND PAI	RALLEL TO	SWELLS
Doors		UNLATCH
Touchdown		LEVEL ATTITUDE
	at est	tablished rate of descent
Face	CUSHION	I at touchdown with coat
Airplane		EVACUATE
Life vests/r	aft	INFLATE

Fires, Icing, Flat Tire, Electrical

Engine Fire Du	ring Start On Ground
Cranking	CONTINUE
If engine starts:	
Power	1700 RPM for a few minutes
Engine	SHUTDOWN
If engine fails to	start:
Throttle	FULL OPEN
Mixture	CUT-OFF
Cranking	CONTINUE for 2-3 minutes
Fire extinguish	er OBTAIN
Master	OFF
Magnetos	OFF
Fuel valve	OFF
Fire	EXTINGUISH
Use fir	e extinguisher, seat cushion,
wool b	lanket, or dirt. If practical, try
to rem	nove air filter if it is ablaze.
Both cases: insp	ect and repair damage
hefore conducting	a another flight

Both cases: inspect and repair damage
before conducting another flight.

Engine Fire in Flight		
Mixture	CUT-OFF	
Fuel valve	OFF	
Master	OFF	
Cabin heat & air	OFF	
(except ov	verhead vents)	
Airspeed	100 KIAS	
If fire is not extinguished, increase		
glide speed to find an airspeed which		
will provide an incombu	ıstible mixture	
Forced Landing With	EXECUTE	
Engine Failure checklist		

Electrical Fire in Flight	
Master	OFF
All other switches (except magnetos)	OFF
Vents/cabin air/heat	CLOSE
Fire extinguisher	USE
If fire appears out and electrical power necessary to continue flight:	is
Master	ON
Circuit breakers	CHECK
(do not reset faulty	circuit)
Radio/electrical switches	ON
One at a time with delay a	fter
each until short circuit is lo	calized
Vents/cabin air/heat	OPEN
(when fire completely exting	uished)

Cabin Fire	
Master	OFF
Vents/cabin air/heat	CLOSED
	(to avoid drafts)
Fire extinguisher	USE
WARNING: After discharg	ging extinguisher
within a closed cabin, ve	entilate cabin
Land ASAP, inspect for damage	ge

willig Fire	
Nav lights	OF
Pitot heat	OF
NOTE: Sideslip to keep flames away fron	ก fuel
tanks and cabin. Land ASAP using flaps	only
as required.	

l	Inadventent Icing Encount	ter		
l	Pitot heat	ON		
l	Turn back or change altitude	to obtain an OAT		
ı	less conducive to icing.			
l	Cabin heat	FULL ON		
ı	Defroster	OPEN		
	Cabin air	ADJUST		
	Maximize defroster heat and airflow			
	Throttle	OPEN		
l	Carburetor/air filter icing	MONITOR		
ı	Apply carb heat as requi	•		
J	for maximum RPM if used continuously			
ı		EAREST AIRPORT		
ı	With very rapid ic	• •		
l	suitable off-airpor			
ı	With $\geq 1/4$ inch ice on the lea			
l	prepare for significantly high	•		
ı		EAVE RETRACTED		
ı	·	Open left window and scrape ice from		
		windshield, if necessary for visibility		
	Forward slip if necessary for	65-75 KIAS		
	Approach speed Depending on level			
l	, ,	in level attitude		
ı	Landing	i iii ievei attituue		

Static Source Blockage					
Alternate static source	valve	PULL ON			
Airspeed	Use	calibration table			
	i	n POH section 5			

Landing With a Flat Main Tire		
Approach	NORMAL	
Touchdown	GOOD TIRE FIRST	
Hold airplane off flat t	ire as long as possible	

Over-Voltage Light Illuminates	
Master	OFF (both sides)
Master	ON
If over-voltage light	illuminates again:
Flight	TERMINATE ASAP

Ammeter Si	nows Discharge	
Alternator		OFF
Nonessential	electrical equipment	OFF
Flight	TERMINATE as soon as	s practical
	Alternator Nonessential	Nonessential electrical equipment