
Quick Start Guide

OpenEVSE

Electrical Requirements

NEMA 14-50 commonly called an "RV outlet" is recommended to charge your vehicle Level 2 at up to 40A.



NEMA 14-50

Mount Charging Station

Mount charging station using appropriate method for the mounting surface. Visit our online guide for more detail.

- **Portable** Mark 2 center holes top and bottom if you plan to use your Charging station on the road. It will be very easy to remove.
- **Static** For more static install, mark the 4 corner holes.

Color Display

Visualize the status of your station from a distance with color

- Ready - Green
- Connected -Yellow
- Charging - Blue
- Error - Red
- Sleeping - Purple

Connect WiFi

Connect charging station to your WiFi network with a phone, tablet, or computer. Visit our online guide for more detail.

- Network: OpenEVSE_XXXXXX
- Password: openevse
- Open web browser enter openevse.local or 192.168.4.1
- select your network
- enter your network password
- reconnect your device to your network
- reconnect to openevse.local

Support

Contact us with any questions

Web: support.openevse.com
E-mail: support@openevse.com
Phone: (877) 967-3638

Guides

Learn more advanced topics with our online guides

Web: guides.openevse.com

Returns

Return your product? Please contact support and return products to:

OpenEVSE Store
132 Landau Rd
Waxhaw, NC 28173

Copyright 2020 – OpenEVSE LLC

Quick Start Guide

Set Charge Current


Set charge current with WiFi or the pushbutton. Absolute maximum is 80% of the Circuit Rating.

- 50A Breaker - 40A Charging
- 40A Breaker - 32A Charging
- 30A Breaker - 24A Charging
- 20A Breaker - 16A Charging
- 15A Breaker - 12A Charging

Push Button

- Long Press to enter Menu
- Quick Press to Scroll options
- Long Press to select Current
- Quick Press until desired setting
- Long Press to select


WiFi




Set a Timer

Set a START and STOP timer to charge the vehicle during the desired time.

- Verify the clock is set.
- Click Sync to set clock




- Set START time
- Set STOP time
- Click Set



Set Session Options

Set a limit for your current charge session. Limit your charge either in minutes or energy.

- Plug Vehicle in
- Select Time in Minutes



- or Select Energy in kwh

