



DESIGN SPAN HP PANEL









DESIGN SPAN HP



PANEL INFORMATION











EAVE - WITH GUTTER





STEP 2



STEP 3

APPLY 3/8" BEAD OF NON-SKINNING BUTYL SEALANT ON BOTH SIDES AND TOP OF MALE PANEL RIB BEFORE ENGAGING FEMALE RIB OF NEXT PANEL






NOTE: STANDARD FACTORY NOTCH IS 1-1/8". LONG LENGTH PANEL INSTALLATIONS REQUIRE GREATER FIELD NOTCHING DEPTH.




DESIGN SPAN HP




EAVE HEM








EAVE (WIDE BATTEN)






NOTE: THE USE OF THIS DETAIL IS NOT RECOMMENDED IN SNOW CLIMATES.



DESIGN SPAN HP

FASCIA TRANSITION / WALL

DESIGN CAUTION:
ROOF SLOPE TRANSITIONS SUCH
AS FASCIAS MAY ESTABLISH AN
UNWANTED POINT OF PANEL
FIXITY. CONTACT YOUR AEP SPAN
REPRESENTATIVE FOR ASSISTANCE.



NOTE:
THE USE OF THIS DETAIL IS NOT RECOMMENDED IN SNOW CLIMATES.





DESIGN SPAN HP

.

FASCIA TRANSITION

FIELD CUT SIDES OF BATTEN CAP. NOTCH BOTTOM LEGS OF UPPER PORTION OF BATTEN CAP AS REQUIRED (VARIES PER ROOF SLOPE). BEND LOWER PORTION OF BATTEN CAP INTO PLACE. FASTEN IN PLACE WITH 1/8" RIVETS, BOTH SIDES.






DESIGN CAUTION:
ROOF SLOPE TRANSITIONS SUCH
AS FASCIAS MAY ESTABLISH AN
UNWANTED POINT OF PANEL
FIXITY. CONTACT YOUR AEP SPAN
REPRESENTATIVE FOR ASSISTANCE.




DESIGN SPAN HP

FASCIA TRANSITION (WIDE BATTEN)




NOTE: FIELD CUT FIRST AND LAST PANELS TO EQUAL WIDTH







DESIGN SPAN HP

GABLE






ALTERNATE UPPER DETAIL




ALTERNATE LOWER DETAIL




DESIGN SPAN HP




SIDE WALL (ALT. DETAILS)







RIDGE / HIP




NOTE:

* ADDITIONAL FASTENERS MAY
BE REQUIRED IN HIGH SNOW
LOAD AREAS. SEE APPENDIX.



DESIGN SPAN HP

RIDGE / HIP (WIDE BATTEN)



NOTES:


- △ CUSTOMER MUST PROVIDE VENT AREA REQUIREMENTS
- * ADDITIONAL FASTENERS MAY BE REQUIRED IN HIGH SNOW LOAD AREAS. SEE APPENDIX.





DESIGN SPAN HP



RIDGE - VENTED












EAVE - HIGH





NOTE: REFER TO EAVE & RIDGE DETAILS FOR FURTHER INFORMATION ON PROPER PANEL TERMINATIONS.



DESIGN SPAN HP

SLOPE TRANSITION









4

VALLEY

ROOF JACK








DESIGN SPAN HP

ROOF PENETRATIONS







ROOF CURB (SIDE WALL FLASHING)

