

## NOTES:

- 1. PRIOR TO SPLICING, CLEAN EXISTING EPDM MEMBRANE BY SCRUBBING THE SPLICE AREA WITH WEATHERED MEMBRANE CLEANER; ALLOW TO DRY.
- 2. CONTACT MANUFACTURER OF EXISTING EPDM MEMBRANE ROOFING SYSTEM TO VERIFY ACCEPTANCE OF TIE-IN AND TO NOT VOID EXISTING WARRANTY.
- 3. ON EXISTING BALLASTED ROOFING SYSTEMS, CONSULT RESPECTIVE MANUFACTURER FOR ACCEPTABLE GRAVEL CONTAINMENT TO PREVENT GRAVEL MIGRATION.
- 4. WATER CUT-OFF MASTIC MUST BE HELD UNDER CONSTANT COMPRESSION.
- 5. WHEN RE-ROOFING OVER PRE-CAST CONCRETE, APPLY LIBERAL BEAD OF WATER CUT-OFF MASTIC IN THE JOINTS TO PREVENT MOISTURE MIGRATION.
- 6. ON MECHANICALLY FASTENED SYSTEMS, CD-10 OR HD 14-10 FASTENERS AND SEAM FASTENING PLATES ARE REQUIRED OVER CONCRETE DECKS.
- 7. ALL SPLICE INTERSECTIONS MUST BE OVERLAID WITH PRESSURE—SENSITIVE T—JOINT COVERS. REFER TO DETAIL U—2A OR DETAIL U—2A.1 FOR WARRANTY PROJECTS EXCEEDING 20—YEARS OR WHEN USING 90—MIL EPDM MEMBRANE.

