

NOTES:

- REFER TO CARLISLE <u>SecurEdge 300</u> <u>INSTALLATION INSTRUCTION MANUAL</u> FOR STEP-BY-STEP INSTALLATION PROCEDURES.
- 2. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF GRAVEL STOP.
- 3. PRESSURE-SENSITIVE T-JOINT COVER OR 6" (152mm) WIDE PRESSURE-SENSITIVE ELASTOFORM FLASHING, IN CONJUNCTION WITH EPDM PRIMER, MUST BE CENTERED OVER FIELD SPLICE AT ANGLE CHANGE.
- 4. AT GUTTER EDGES, SCUPPERS MUST BE PROVIDED FOR DRAINAGE.
- 5. WHEN METAL FASCIA BY OTHERS IS USED, FASTENER TYPE AND FASTENING FREQUENCY SHALL BE RECOMMENDED BY METAL EDGE MANUFACTURER.



