

NOTES:

- DECK FLANGE MUST BE TOTALLY COVERED WITH MINIMUM 2" (51mm) COVERAGE PAST NAIL HEADS.
- 2. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF METAL EDGE.
- 3. TO REMOVE FINISHING OILS, SCRUB METAL FLANGE WITH WEATHERED MEMBRANE CLEANER; ALLOW TO DRY PRIOR TO APPLYING PRIMER.
- 4. LAP SEALANT MUST BE APPLIED AT FLASHING OVERLAPS AND INTERSECTIONS WITH JOINTS IN METAL EDGING.
- 5. ALL SPLICE INTERSECTIONS MUST BE OVERLAID WITH PRESSURE—SENSITIVE T—JOINT COVERS AND SEALED WITH CONTINUOUS LAP SEALANT. PRIOR TO DOING SO, APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE 6"X6" T—JOINT COVER) COVERING THE EXPOSED SPLICE TAPE 1/2" (13mm) IN ALL DIRECTIONS FROM THE SPLICE INTERSECTION.
- 6. REFER TO APPLICABLE CARLISLE METAL

 EDGING INSTRUCTION MANUAL FOR

 STEP-BY-STEP INSTALLATION PROCEDURES.
- 7. DETAIL NOT FOR USE WITH DESIGN "B" (BALLASTED STONE ASSEMBLY).



