



NOTES:

- 1. ALL SPLICE INTERSECTIONS MUST BE OVERLAID WITH TWO LAYERS OF PRESSURE—SENSITIVE ELASTOFORM FLASHING.
- 2. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE COVERING 1/2" (13mm) IN ALL DIRECTIONS FROM THE SPLICE INTERSECTION AND OVERLAY WITH A 6"X6" (152X152mm) T-JOINT COVER. A SECOND LAYER OF 12"X12" (305X305mm) PRESSURE-SENSITIVE T-JOINT COVER IS REQUIRED.
- 3. BOTH LAYERS SHALL BE CENTERED OVER THE SPLICE INTERSECTION AND SEALED WITH CONTINUOUS LAP SEALANT.

