

- SPLICE TWO PIECES OF ELASTOFORM OR PRESSURE-SENSITIVE ELASTOFORM TOGETHER TO ACHIEVE DESIRED WIDTH.
- 2. DRILL A 3/8" (10mm) DIAMETER WEEP HOLE ON THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE PERIMETER TO THE TIE-IN 6" (152mm) FROM THE SEAM FASTENING PLATE.
- 3. ON MECHANICALLY FASTENED SYSTEMS, HP FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
- 4. IF WATER PONDS OR FLOWS OVER TIE-IN FROM BUR SURFACE, USE DETAIL U-13B.
- 5. ON BALLASTED SYSTEMS, USE CONCRETE PAVERS TO PREVENT BALLAST MIGRATION.

