## NOTES:

1. FIELD APPLIED SecurTAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (25mm) AT THE ENDS OF EACH CUT PIECE. APPLY LAP SEALANT AT TAPE OVERLAPS 1/2" (13mm) IN ALL DIRECTIONS AS SHOWN.

F.A.T.

(FACTORY APPLIED SecurTAPE)

- 2. ALL SPLICE INTERSECTIONS MUST BE OVERLAID WITH TWO LAYERS OF PRESSURE-SENSITIVE ELASTOROM FLASHING. BOTH LAYERS SHALL BE CENTERED OVER THE SPLICE INTERSECTION AND SEALED WITH CONTINUOUS LAP SEALANT.
- 3. END LAPS SHALL BE SPLICED USING 6" (152mm) WIDE SecurTAPE.

FIELD APPLIED SecurTAPE

4. LAP SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED EPDM MEMBRANE.

