Interior Extension Jamb Installation Guide

for Andersen® Architectural Fixed Windows

Andersen

architectural windows and doors

IMPORTANT

Read all instructions carefully before attempting this procedure. If you have any questions about your ability to complete this procedure, call Andersen at 1-888-888-7020 for further direction. Andersen WindowCare® service center hours are Monday through Friday, 7 a.m. to 7 p.m. Central Time and Saturday 8 a.m. to 4 p.m. Central Time. Thank you for choosing Andersen® products.

Important Safety, Assembly, and Installation Information

Every assembly and installation is different (windloads, structural support, etc.). Andersen strongly recommends consultation with an Andersen supplier or an experienced contractor, architect, or structural engineer prior to the assembly and installation of any Andersen product. Andersen has no responsibility in regard to the post-manufactured assembly and installation of Andersen products.

A WARNING

Using ladders and/or scaffolding and working at elevated levels may be hazardous. Follow equipment manufacturer's instructions for safe operation. Use extreme caution when working around window and door openings. Falling from opening may result in injury or death.

A WARNING

Improper use of hand/power tools could result in injury and/or product damage. Follow manufacturer's instructions for safe operation of equipment. Always wear safety glasses.

A WARNING

Windows and doors can be heavy. Use safe lifting techniques and a reasonable number of people with enough strength to lift, carry and install window and door products to avoid injury and/or product damage.

Parts Included

Instruction Guide Extension Jamb Set

Tools and Supplies


- Safety Glasses
- Pencil
- Mitre Saw
- Power Drill
- Phillips Screwdriver
- #6 x 1-5/8" Trim Screw
- #8 x 1-1/2" Pan Head Screw
- 7/32" Drill Bit

- 5/16" Drill Bit
- 1/8" Drill Bit
- 3/32" Drill Bit

Extension Jamb Offset

NOTICE

- Thin Jamb units have a 7/64" offset between Frame and Extension Jamb.
- On Thick Jamb units the inside surface of Extension Jamb is flush with inside surface of Frame.



"Andersen" is a registered trademark of Andersen Corporation. All other marks where denoted are marks of Andersen Corporation.

Extension Jamb Application Before Unit Installation

1. Cut Extension Jambs to Size


CAUTION

Curved Extension Jambs can be pushed inwards. **Do Not** push curved Extension Jambs outwards or over compress inwards. Forcing Extension Jambs too far will cause product damage.

NOTICE

Extension Jambs are sent long and must be cut to fit on site.

- Place Extension Jambs in position on window unit. Allow for 7/64" offset on Thin Jamb units. Curved Extension Jambs can be pushed inward slightly to better fit window frame. Do Not force curved Extension Jambs outwards.
- Mark and cut Extension Jambs to size with mitre saw.




2. Predrill Extension Jambs

Extension Jambs 2" or Wider

- Drill through groove on back side of Extension Jamb on 15° angle with 1/8" drill bit. See drawing.
- For *Extension Jamb* with no groove. Drill 1/8" hole on 15° angle 1-3/8" from edge. Counterbore with 5/16" drill bit stopping 5/8" from edge. See drawing.
- Drill holes 3" from each end and every 12" to 16" between.


Extension Jambs Less Than 2" Wide

- Drill 3/32" hole through middle of interior edge. Counterbore Extension Jambs wider than 1" with 7/32" drill bit. Counterbore from interior edge and stop 3/4" from other edge.
- Drill holes 3" from each end and every 12" to 16" between.



3. Install Extension Jamb

- Install curved or head Extension Jamb first. Install side Extension Jambs second and sill Extension Jamb last.
- Place Extension Jambs in position.
 Maintain 7/64" offset on Thin Jamb units.
- Secure Extension Jambs with screws. If securing through back side of Extension Jambs use #8 x 1-1/2" pan head screws. If securing through the interior edge use #6 x 1-5/8" trim screws.
- Predrill and secure corners of Extension Jambs using #6 x 1-5/8" trim screws.
 See drawing.




Extension Jamb Application After Unit Installation

NOTICE

After window unit has been installed, follow steps for Extension Jamb Application Before Unit Installation if possible. For Extension Jambs 2" or wider not able to secure from back side, secure through interior edge.

- Predrill through middle of interior edge of Extension Jamb with 3/32" drill bit. Drill holes 3" from each end and every 12" to 16" between.
- Counterbore Extension Jambs wider than 1" with 7/32" drill bit. Counterbore from interior edge and stop 3/4" from other edge.
- Secure Extension Jamb with #6 x 1-5/8" trim screws.




Elliptical Extension Jambs


NOTICE

Elliptical Extension Jambs can be supplied in 2 or 3 pieces. Extension Jambs are sent long and must be cut to fit on site.

• Mark, cut, predrill and install the *Extension Jambs* as described in previous sections.



2 Piece Elliptical Construction




3 Piece Elliptical Construction

Drywall Kerf

NOTICE

The drywall kerf is a groove cut in the interior edge of the frame or Extension Jamb which allows the leg of a drywall return to be inserted as shown in the drawing. Drywall return is supplied by others.



Finishing and Maintenance

CAUTION

DO NOT expose unfinished wood to high moisture conditions, excessive heat or humidity. Finish wood surfaces immediately after installation. Unfinished wood surfaces will discolor, deteriorate, and/or may bow and split.

SURFACE PREPARATION

Set all nails 1/16" below wood surface. Fill all nail holes. Lightly sand all surfaces with 220 grit sandpaper. Remove all dust with a tack cloth or clean damp rag.

FINISHING

Read and follow finishing manufacturer's instructions and warnings on each container of finishing material for priming, painting, staining, and varnishing.

MAINTENANCE

Immediately sand and refinish any wood that becomes stained or mildewed to prevent further discoloration and/or damage. For further information, contact your local Andersen Dealer. Dealers can be found in the Yellow Pages under Windows.

