

This is the front of the panel.
In this configuration, the panels are installed from Left to Right. The anchor is set into the Left panel then secured to the structure. The tongue of Right panel is then placed into the groove of the left and covers the anchor.

Aluminum anchor (code 4050)
The anchor and panel are designed to fit together without putting any holes in the panel.
This is the back side of the 547

This is the back side of the 547 panel.