# Ultrasound headset assy

PH 7/5/2023

- Cut two wires to 58-59 mm
- Insert both to lever arms




 Load arms into transducer base




- Tap cap with M5 tap
- Drop pusher into cap





 Lower cap on to housing base




- Screw cap on to the base from the back side using M3 plastic screw
- Screw with T-10 star torque head driver



- Place transducer on the back housing
- Lay in with a tilt first



- Push back base housing transducer snaps
- Push in transducer flat until snaps engage



- Secure with transducer secure straps
- Place M1.6 screws
- Screw with T-5 torque driver



 Attach one side of the end block to the Headband



 Screw 2 M3 screws to secure end block



 Load FUHB slider to headband tracks



 Assembly lever bracket to lever



Add lever assembly to headband



 Screw bracket to the headband from the backside with the 1.6 mm screws



 Screw on the second end block



 Thread slippery cord though levers and end nut


Ordered tube was wrong should reorder



Insert nut into endblock slot




 Install endblock on other side




• Thread strap end first

Extra straps not found, order more



Add center foam pad

PSA not sticky enough



 Add two foam pressure pads

PSA not sticky enough



## Eat cake @ finish line

