



AQ-MF-1-R

Under Sink Water Filter


Claryum® Direct Connect

REPLACEMENT


Owner's Manual For use with AQ-MF-1

NOTE: Upon installation, write the date of installation on the filter label as a reminder of when you will need to replace the filter.

1 Turn off COLD water supply under the sink.




Remove the old filter from the system head. Rotate the filter to the left until it unlocks, pull down and discard.



3 To attach new filter to the system, align all connection points, push in, and turn filter to the right until it locks.


NOTE: Do not use tools to tighten. Hand tighten only.



INSTALLATION STEPS



Once filter is locked into place, turn on the COLD water supply to pressurize the system. Check for leaks.



5

Turn on kitchen faucet to COLD water and run water through the system at least for at least 15 minutes. Once the system is flushed, turn off kitchen faucet.

NOTE: Do not drink flushed water.

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.



Scan to view the Claryum[®] Direct Connect replacement video.





System certified by IAPMO R&T against NSF/ANSI Standards 42, 53, and 401 for the reduction of the claims specified on the Performance Data Sheet and at www.IAPMO.org.



For the full list of contaminants filtered, scan to view the Performance Data Sheet on Aquasana.com.

The recommended replacement frequency for the AO-MF-1-R is every 6 months or every 784 gallons of use. Use only certified, genuine Aquasana replacement filters for continued contaminant removal and system performance.

Aquasana, Inc.

6310 Midway Road Haltom City, Texas 76117 866.662.6885 USA 877.332.7873 Canada www.aquasana.com