# FCC/CE 认证样品 -流程说明



## **OPULINKS**

http://www.opulinks.com/

Copyright © 2020, Opulinks. All Rights Reserved.

## 目录

1.	操作接口	1
	1.1. WIFI 定频操作说明	2
	1.2. Bluetooth 定频操作说明	4
2.	O&A	5



## 1. 操作接口

旺凌芯片支持 RF 认证试验,藉由 AT Command 可指定频道与收发功能。

```
COM3:115200baud - Tera Term VT
                                                        Х
File Edit Setup Control Window Help
><CHECK>
SPI load patch, last index 0 result 2
This image is from MW_OTA [0].
<AGENT>
SPI load patch, last index 486 result 2
BootMode 10
The init of MW FIM is done.
[OPL1000 A2 PATCH]
wifiMac Task create successful
Supplicant task is created successfully!
controller_queue creates successful!
controller_queue_ble creates successful!
controller task create successful!
LE Task create successful
This image is from MW_OTA [0].
AppInit
 itchat
Switch: AT UART
>at+sysmode=1
OK
>at+mode=3
>Mode is RF
OΚ
```



# **CHAPTER ONE**

## 1.1. WIFI 定频操作说明

#### 步骤1

指令	说明	响应
at+sysmode=1	设定 system mode=1,	OK
	进入产测模式(MP mode)	

#### 步骤 2

指令	说明	响应
at+mode=3	进入 wifi 测试模式	Mode is RF OK

#### 步骤 3

指令	说明	响应
at+channel=[ch#]	[ch#] : 请设定信道频率值为 1~14	5, [ch#] OK

#### 步骤 4

指令	说明	响应
at+tx=1	开始送讯号	OK



# **CHAPTER ONE**

#### 步骤 5

指令	说明	响应
at+tx=0	结束送讯号	OK

#### 步骤6

指令	说明	响应
at+rx=1	开始收讯号	OK

#### 步骤 7

指令	说明	响应	
at+rx=0	结束收讯号	ОК	



# **CHAPTER ONE**

## 1.2. Bluetooth 定频操作说明

#### 步骤1

指令	说明	响应
at+sysmode=1	设定 system mode=1,	ОК
	进入产测模式(MP mode)	

#### 步骤 2

指令	说明	响应
at+dtm=tx,[phy ch],37,[delta F#]	开始送讯号	ОК
	   <i>[phy ch]:</i> 请设定 phy 信道频率	
	[deLta F#]:Delta F1 请设定 1	
	[deLta F#]:Delta F2 请设定 2	

#### 步骤 3

指令	说明	响应
at+dtm=end	结束讯号	ОК



# **CHAPTER TWO**

## 2. Q&A

Q1. RF 规格是 BT 跟 WIFI 吗?

A: 是的

Q2. WiFI 频段是 802.11b/g/n20/n40 吗?

A: 802.11b

Q3. 使用软件

A. Tera Term

→ https://ttssh2.osdn.jp/index.html.en

