31	27	26	25	24	20	19	15	14	12	11	7	6	0	
	funct7				rs2	rs	1	fun	ct3		rd	opo	code	R-type
	imm[11:0]				rs1		fun	ct3	rd		opo	code	I-type	
	imm[11:5	5]			rs2	rs	1	fun	ct3	imr	n[4:0]	opo	code	S-type
i	mm[12 10]	0:5]			rs2	rs	1	fun	ct3	imm	[4:1 11]	opo	code	B-type
	imm[31:12]									rd	opo	code	U-type	
	imm[20 10:1 11 19:12]									rd	opo	code	J-type	

RV32I Base Instruction Set

			- DOLDO IIIDUI	CICCIOII O	~ ~		
		imm[31:12]	rd	0110111	LUI		
		imm[31:12]	rd	0010111	AUIPC		
	imr	n[20 10:1 11 1	rd	1101111	JAL		
	nm[11:0	0]	rs1	000	rd	1100111	JALR
imm[12 10]	imm[12 10:5] rs2			000	imm[4:1 11]	1100011	BEQ
imm[12 10]):5]	rs2	rs1	001	imm[4:1 11]	1100011	BNE
imm[12 10]):5]	rs2	rs1	100	imm[4:1 11]	1100011	BLT
imm[12 10]	imm[12 10:5]		rs1	101	imm[4:1 11]	1100011	BGE
imm[12 10]	imm[12 10:5]		rs1	110	imm[4:1 11]	1100011	BLTU
imm[12 10]	imm[12 10:5] rs2			111	imm[4:1 11]	1100011	BGEU
in	nm[11:0	0]	rs1	000	rd	0000011	LB
in	nm[11:0	0]	rs1	001	rd	0000011	LH
in	nm[11:0	0]	rs1	010	rd	0000011	LW
in	nm[11:0	0]	rs1	100	rd	0000011	LBU
in	nm[11:0	0]	rs1	101	rd	0000011	LHU
imm[11:5	5]	rs2	rs1	000	imm[4:0]	0100011	SB
imm[11:5	5]	rs2	rs1	001	imm[4:0]	0100011	SH
imm[11:5	5]	rs2	rs1	010	imm[4:0]	0100011	SW
in	nm[11:0	0]	rs1	000	rd	0010011	ADDI
	nm[11:0		rs1	010	rd	0010011	SLTI
in	nm[11:0	0]	rs1	011	rd	0010011	SLTIU
in	nm[11:0	0]	rs1	100	rd	0010011	XORI
in	nm[11:0	0]	rs1	110	rd	0010011	ORI
in	nm[11:0	0]	rs1	111	rd	0010011	ANDI
0000000)	shamt	rs1	001	rd	0010011	SLLI
0000000)	shamt	rs1	101	rd	0010011	SRLI
0100000)	shamt	rs1	101	rd	0010011	SRAI
0000000		rs2	rs1	000	rd	0110011	ADD
0100000		rs2	rs1	000	rd	0110011	SUB
0000000		rs2	rs1	001	rd	0110011	brack SLL
0000000)	rs2 rs2	rs1	010	rd	0110011	SLT
0000000	0000000		rs1	011	rd	0110011	SLTU
0000000	0000000		rs1	100	rd	0110011	XOR
	0000000		rs1	101	rd	0110011	ceil SRL
0100000	0100000		rs1	101	rd	0110011	SRA
	0000000 rs2			110	rd	0110011	OR
0000000	0000000		rs1	111	rd	0110011	AND
0000	pre	d succ	00000	000	00000	0001111	FENCE
0000	000		00000	001	00000	0001111	FENCE.I
	000000		00000	000	00000	1110011	ECALL
000	000000	001	00000	000	00000	1110011	EBREAK
	csr		rs1	001	rd	1110011	CSRRW
	csr		rs1	010	rd	1110011	CSRRS
	csr		rs1	011	rd	1110011	CSRRC
	csr		zimm	101	rd	1110011	CSRRWI
	csr		zimm	110	rd	1110011	CSRRSI
	csr		zimm	111	rd	1110011	CSRRCI