

Shopkeeper Guide

Welcome to the AutoPrint Kiosk Pilot program! This guide will walk you through setting up, configuring, and operating your automated printer station.

How the System Works

Step 1: Scan QR	Step 2: Upload File	Step 3: Approval	Step 4: Automatic Print
Customer scans the unique counter QR code at your shop.	Customer uploads PDF, configures copies, duplex, and color mode.	If print mode is Manual , you approve it in the Console. If Auto , it skips approval.	The Desktop Agent downloads the job and sends it directly to your physical printer.

1. Desktop Agent Setup

The Windows Desktop Agent acts as the bridge connecting your physical USB/Network printer to the cloud queue.

- **Download & Install:** Access the download link from your main Shop Dashboard to retrieve the installer bundle.
- **Run Background Service:** Open **AutoPrint.exe**. It runs in the background and places a tray icon on the bottom-right taskbar tray.
- **Status Tray Icons:** Monitor the tray icon colors for instant status checks:

Icon State	Meaning	Required Action
■ Green (Ready)	Agent is online, polling jobs, and connected to the database.	No action required. Ready to process prints.
■ Blue (Printing)	Agent is downloading, spooling, or printing a file.	Wait for spooling to finish and printer to complete job.
■ Red (Offline/Error)	Disconnected from database, or physical printer queue is stalled.	Check internet connection, or restart the agent.

- **Configuring Printer:** Right-click the tray icon and select *Configure* to verify/select your physical printer destination.

2. Managing Queue & Print Modes

Open the web portal on your phone or PC and navigate to the **Shopkeeper Dashboard**:

- **Manual Approval Mode (Recommended for pilot)**: Each job enters a 'Pending Approval' queue. Review the page counts and collect cash first, then click **Approve & Print**. This prevents customers from wasting paper.
- **Auto-Print Mode**: Jobs bypass approval and spool directly. Ideal if you want a complete hands-off self-service kiosk (requires digital pre-payment integration in next phase).
- **Live Connectivity Card**: The dashboard displays ■ **Agent Online** or ■ **Agent Offline** status. The online state updates automatically based on a 20-second heartbeat from your physical computer.

3. Rates & Cash Collection Flow

AutoPrint automatically calculates the price of each print job so you can charge customers instantly. The system supports distinct pricing configurations.

To change your default rates:

1. Go to the dashboard/console header and click the ■ **Change Rates** link.
2. Update rates for Black & White (Single Side), Black & White (Double Side), Color (Single Side), and Color (Double Side).
3. Click **Save Rates**. Calculations update immediately for new files in your console.

Cash Collection Flow Tip: Before clicking *Approve & Print* in manual mode, confirm the total price shown in the **Collect Price** badge (e.g. ■12.00). Collect cash or standard QR payment from the customer, then trigger the approval to spool the physical printout.

4. Operational Troubleshooting

Symptom	Likely Cause	Resolution Checklist
Dashboard shows ■ Agent Offline	• Windows agent is closed. • PC went to sleep. • No internet connection.	1. Check Windows system tray for the icon. 2. Double-click AutoPrint.exe to restart. 3. Turn off PC Sleep Mode in Windows settings.
Job Status shows Failed	• PDF reader path invalid. • Spooler is offline. • Jammed/out of paper.	1. Right-click tray and verify the selected printer name. 2. Open the job details in the console to read error logs. 3. Click Retry once paper is cleared.
Incorrect price calculation	• Standard base rates need adjusting.	1. Access Change Rates setting. 2. Save settings and reload page.

Need Help? Pilot Operations Support: Contact your AutoPrint representative immediately for any hardware configuration, software bugs, or general feedback. We are here to support your operations!