Utilization (%)	Zone Type	Typical Application
0-25	significant excess	various
	processing power – CPU	
	may be more powerful than	
	necessary	
26-50	very safe	various
51-68	safe	various
69	theoretical limit	embedded systems
70-82	questionable	embedded systems
83-99	dangerous	embedded systems
100+	overload	stressed systems