

UNDERSTANDING CAVITATION

AXIOM ENGINEERING RESOURCE

How to recognize, prevent, and troubleshoot cavitation in industrial pumping systems.

01 Recognize the signal

Noise, vibration, unstable flow, or a loss of head can indicate cavitation. Check the symptoms against suction pressure, temperature, and operating point.

02 Find the cause

Review available NPSH, suction line losses, valve position, strainer condition, fluid vapor pressure, and changes to upstream equipment.

03 Make it durable

Correct the hydraulic condition, document the new operating limits, and align control logic and maintenance checks so the issue does not return.

This reference is intended to support early-stage engineering conversations. Final selection and compliance requirements remain project-specific.