

REDUCING ENERGY IN FLOW SYSTEMS

AXIOM ENGINEERING RESOURCE

Where system modernization can create measurable, sustained operating savings.

01 Measure the baseline

Capture flow, pressure, control positions, run hours, and energy use across the real operating profile rather than relying on a single design point.

02 Remove avoidable work

Review unnecessary restriction, fixed-speed assumptions, pipework losses, and oversizing. Variable speed can help where the duty and controls support it.

03 Verify the saving

Define post-commissioning setpoints and a simple review cadence so the measured improvement stays visible to the operating team.

This reference is intended to support early-stage engineering conversations. Final selection and compliance requirements remain project-specific.