
Example for First Stage LP test

Deposit system:



System matrix:

Dynamic matrix. Matrix nxn.

$$A = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix}$$

Control Matrix. Matrix nxM.

$$B = \begin{bmatrix} B1 & -B2 & 0 & -B4 \\ 0 & B2 & -B3 & 0 \\ 0 & 0 & B3 & B4 \end{bmatrix}$$

Disturbance matrix,

$$Bw = \begin{bmatrix} -Qs1 & Qe2 - Qs2 & -Qs3 \end{bmatrix}$$