



EC-310 Microprocessor & Microcontroller based Design

Dr. Ahsan Shahzad

Department of Computer and Software Engineering (DC&SE)

College of Electrical and Mechanical Engineering (CEME)

National University of Sciences and Technology (NUST)

PIC Programming in C

- Compilers produce hex files that we download into the ROM of the microcontroller.
- The size of hex file is critical as Microcontrollers have limited on-chip ROM.
- Assembly language produces hex file much smaller than C.

Pros of Programming PIC18 in C

- Easier and less time consuming than assembly
- C programs easier to modify and update
- Availability of function libraries
- C code is portable to other microcontrollers

Cons

Increased size of hex file



PIC C18 Compilers

Role of compiler in PIC18 programming in C

- The data types supported, the types of operations performed, and the syntax depends upon the compiler used
- Even the number of bits allocated to each data type depend on the compiler used
- Generally, all the compilers use the syntax derived from ANSI C standard
- However, they are not 100 percent compliant with all the ANSI C standards

Examples:

- 1. Microchip C18 compiler: really the best and easiest to use. Perfect for professional use.
- 2. HI-TECH: Used when Microchip does not work (it was for a PIC16).
- 3. <u>CCS</u>
- 4. SourceBoost



MPLAB C18 Compiler

- The MPLAB C18 compiler is designed for the PIC18 family of microcontrollers
- The focus in this course is on the C18 compiler.
- This is ANSI C 89 Compliant
- For further details visit
- http://ww1.microchip.com/downloads/en/DeviceDoc/MPLAB C18 Users Guide 5128
 8d.pdf

C Data types for the PIC18

Goal: C18 programmers is to create smaller hex file

Good understanding and proper use of data types is essential for this.

TABLE 2-1: INTEGER DATA TYPE SIZES AND LIMITS

Type	Size	Minimum	Maximum
char ^(1,2)	8 bits	-128	127
signed char	8 bits	-128	127
unsigned char	8 bits	0	255
int	16 bits	-32,768	32,767
unsigned int	16 bits	0	65,535
short	16 bits	-32,768	32,767
unsigned short	16 bits	0	65,535
short long	24 bits	-8,388,608	8,388,607
unsigned short long	24 bits	0	16,777,215
long	32 bits	-2,147,483,648	2,147,483,647
unsigned long	32 bits	0	4,294,967,295

Note 1: A plain char is signed by default.



C Data types for the PIC18

Goal: C18 programmers is to create smaller hex file

Good understanding and proper use of data types is essential for this.

2.1.2 Floating-point Types

32-bit floating-point types are native to MPLAB C18 using either the double or float data types. MPLAB C18 utilizes the IEEE-754 floating-point standard to represent floating-point types. The ranges of the floating-point type are documented in Table 2-2.

TABLE 2-2: FLOATING-POINT DATA TYPE SIZES AND LIMITS

Туре	Size		Maximum Exponent	Minimum Normalized	Maximum Normalized
float	32 bits	-126	128	2 ⁻¹²⁶ ≈ 1.17549435e - 38	$2^{128} * (2-2^{-15}) \approx 6.80564693e + 38$
double	32 bits	-126	128	2 ⁻¹²⁶ ≈ 1.17549435e - 38	$2^{128} * (2-2^{-15}) \approx 6.80564693e + 38$

Example: Unsigned Char

Example 7-1 Write a C18 program to send values 00—FF to Port B. Solution: //for TRISB and PORTB declarations #include <P18F458.h> void main(void) unsigned char z; //make Port B an output TRISB = 0;for(z=0;z<=255;z++) PORTB = Z;while(1); //NEEDED IF RUNNING IN HARDWARE

Run the above program on your simulator to see how Port B displays values 00-FFH in binary. Notice that "while(1)" is needed if this program is running in hardware.

Example: Strings - Character Array

```
Example 7-2
Write a C18 program to send hex values for ASCII characters of 0, 1, 2, 3, 4, 5, A, B,
C, and D to Port B.
Solution:
#include <P18F458.h>
void main (void)
     unsigned char mynum[] = "012345ABCD"; //data is stored in RAM
     unsigned char z;
     TRISB = 0;
                                //make Port B an output
     for (z=0; z<10; z++)
       PORTB = mynum[z];
                            //stay here forever
     while(1);
Run the above program on your simulator to see how Port B displays values 30H,
```

31H, 32H, 33H, 34H, 35H, 41H, 42H, 43H, and 44H (the hex values for ASCII 0, 1,

in hardware. This is like "GOTO \$" or "BRA \$" in Assembly language.

2, etc.). Notice that the last statement "while(1)" is needed only if we run the program

Example: Signed Char

Example 7-4

Write a C18 program to send values of -4 to +4 to Port B.

Solution:

Run the above program on your simulator to see how PORTB displays values of 1, FFH, 2, FEH, 3, FDH, 4, and FCH (the hex values for +1, -1, +2, -2, etc.). See Chapter 5 for discussion of signed numbers.

Example: Unsigned short long

```
Example 7-6
Write a C18 program to toggle all bits of Port B 100,000 times.
Solution:
//toggle PB 100,00 times
#include <P18F458.h>
void main(void)
     unsigned short long z;
     unsigned int x;
     TRISB = 0;
                                //make Port B an output
     for(z=0;z<=100000;z++)
          PORTB
                 0x55;
          PORTB
               = 0xAA;
                                //stay here forever
     while(1);
```

Time Delays in C

Two ways to create time delay in C18

- For **loop** approximate method
- PIC18 **Timers** Accurate

Time delay using for loop

Two factors that can affect the accuracy of delay:

- Crystal frequency connected to OSC1-OSC2 input pins
- Compiler- different compilers produce different size hex code

Time Delays in C

Two ways to create time delay in C18

- For loop approximate method
- PIC18 Timers Accurate

Time delay using for loop

Two factors that can affect the accuracy of delay:

- Crystal frequency connected to OSC1-OSC2 input pins
- Compiler- different compilers produce different size hex code

 NOTE: For above reasons, when we write time delays in C using loops, we must use the oscilloscope to measure the exact duration.

Time Delays in C

Example 7-7

Write a C18 program to toggle all the bits of Port B ports continuously with a 250 ms delay. Assume that the system is PIC18F458 with XTAL = 10 MHz. Solution:

```
#include <P18F458.h>
void MSDelay(unsigned int);
void main(void)
                               //make Port B an output
    TRISB = 0;
    while(1)
                               //repeat forever
         PORTB = 0x55;
         MSDelay(250);
         PORTB = 0xAA;
         MSDelay (250);
void MSDelay(unsigned int itime)
    unsigned int i; unsigned char j;
    for(i=0;i<itime;i++)
      for(j=0;j<165;j++);
```

Instruction Cycle – for PIC

The amount of time required by the CPU to execute an instruction is referred to as Instruction cycle (also known as machine cycle in some other CPUs OR fetch-decode-execute cycle).

- Because all the instructions in the PIC18 are either 2-byte or 4- byte, most instructions take no more than **one or two instruction cycles to** execute.
- The crystal oscillator, along with on-chip circuitry, provide the clock source for the PIC MCU.
- In PIC, one instruction cycle consists of four oscillator periods (clock cycles)
- Therefore, Instruction cycle = ¼ of crystal frequency

Delay calculation for PIC18 - Assembly code

For crystal frequency 4MHz, calculate the delay introduced by following program.

From Ap	pendix A, v subroutine:	we have th	e follo	wing machine	cycles	for ea	ch instr	uction	of the
				Instruction	Cycle	•			
DELAY	MOVLW	0xFA		1					
	MOVWF	MYREG		1					
AGAIN	NOP			1					
	NOP			1					
	NOP			1					
DÉ	DECF	MYREG,	\mathbf{F}	1					
	BNZ	AGAIN		2					
	RETURN			1					

Delay calculation for PIC18 – Assembly code

For crystal frequency 4MHz, calculate the delay introduced by following program.

From Appendix A, we have the following machine cycles for each instruction of the DELAY subroutine:

	DELAY st	abroutine:			Instruction	Cvcle			
	DELAY	MOVLW	$0 \times FA$		1				
		MOVWF	MYREG		1				
	AGAIN	NOP			1				
1		NOP			1				
1		NOP			1				
ı		DECF	MYREG,	\mathbf{F}	1				
1		BNZ	AGAIN		2				
		RETURN			1				
	Therefore, we have a time delay of $[(250 \times 6) + 1 + 1 + 1] \times \frac{1 \mu s}{1} = 1503 \mu s$.								