Amina Qadeer

CE-42-A


359607

LAB 09

1) Write 0xAA on PORTB, 0x77 on PORTC and 0xFF on PORTD using MPLAB and show results in Proteus on LEDs. Reset circuit should also be made.

Proteus Simulation:

Example circuit:




#include P18f452.INC org 00h movlw 0H movwf TRISB movlw 0xAA movlw PORTB movlw 0H movwf TRISC movlw 0x77 movwf PORTC movlw 0H movwf TRISD movlw 0xFF


CODE:

END

movwf PORTD



Saving as .hex file



2) Display '5' on a seven-segment display connected on PORTD in Proteus.

CODE:

#include<P18f452.INC>

org 100h

movlw 0h

movwf TRISD

movlw 05H

movwf PORTD

End

