16. CONTENTS OF THE ALTO DISK

The following files are ordinarily kept on the Maxc2 Alto's disk, in addition to standard Alto subsystems.

Maxc-related files

MICRO.RUN Microcode assembler
MIDAS.RUN Microcode loader/debugger

MIDAS.* Various auxiliary files needed by Midas

SYS2.MB PDP-10 emulator microcode

TENLOAD.MIDAS Midas commands to load microcode

INIT.MIDAS Midas commands to load and dump newly-assembled

microcode

MEXECGO.MIDAS Midas commands to load microcode, start Micro-Exec TENGO.MIDAS Midas commands to load microcode, start Tenex

ALTIO.RUN Nova I/O control program

TM.RUN Maxc memory diagnostic (runs on Alto)
MEMBASH.RUN Maxc memory contention exercisor

SMIDIAG.RUN Alto System Maintenance Interface diagnostic

Microprocessor diagnostics and command files

DGBASIC.MB **DGBASIC.MIDAS** DGP.MB **DGP.MIDAS** DGALU.MB **DGALU.MIDAS** DGIMH.MB **DGIMH.MIDAS** DGIML.MB **DGIML.MIDAS** DGRL.MB **DGRL.MIDAS** DGI.MB **DGI.MIDAS** DGM.MB DGM.MIDAS DGMR.MIDAS DGMR.MB DGREG.MB DGREG.MIDAS DBEG.MB

The current microprocessor diagnostic sources are ordinarily kept on the Maxc2 Alto disk as well.