Wiring for firmware programming:

- RX -> TX
- TX -> RX
- CH_PD -> 3.3V
- GPIO 0 -> GND
- VCC -> 3.3V
- GND -> GND