Connect PIR Sensor, Camera module with Raspberry pi

PIR Sensor Pins

Pins	Connection With Raspberry Pi
VCC	Connect Any Power Pin Of Raspberry Pi
GND	Connect Any Ground Pin Of Raspberry Pi
OUT	Connect To GPIO Pin 23

