Single Vehicle Test Results

Generated: 2025-10-11 01:42:30

Anchor Motors ACC System

11-Oct-2025

Table of Contents

| Chapter 1. Summary | |
|--|------------|
| Chapter 2. case 10 lead gradually slows down | |
| Warnings Summary | |
| Unclassified Warnings | |
| Chapter 3. case 1 lead veh sudden stop 25a | 2 |
| Warnings Summary | |
| Unclassified Warnings | |
| Chapter 4. case 2 ego0 gap not desired25a | |
| Errors Summary | 6 |
| Warnings Summary | |
| Unclassified Warnings | <u></u> |
| Chapter 5. case 3 lead rapid increase space | |
| Warnings Summary | |
| Unclassified Warnings | |
| Chapter 6. case 4 lead disappears | 11 |
| Warnings Summary | |
| Unclassified Warnings | <u>1</u> 1 |
| Chapter 7. case 5 lead car appears25a | 13 |
| Warnings Summary | |
| Unclassified Warnings | 13 |
| Chapter 8. case 6 zero relative v high gap | 15 |
| Warnings Summary | 15 |
| Unclassified Warnings | 1 <u>5</u> |
| Chapter 9. case 7 zero relative v low gap | 17 |
| Warnings Summary | 17 |
| Unclassified Warnings | 17 |
| Chapter 10. case 8 sn high neg delta v25a | 19 |
| Warnings Summary | 19 |
| Unclassified Warnings | 19 |
| Chapter 11. case 9 ego stopped lead accelerating | <u>2</u> 1 |
| Warnings Summary | 21 |
| Unclassified Warnings | 21 |

Chapter 1. Summary

Total Tests: 10

Passed: 0

Passed with warnings: 9

Failed: 1

Passed with Warnings Tests:

- case 10 lead gradually slows down
- case 1 lead veh sudden stop 25a
- case 3 lead rapid increase space
- case 4 lead disappears
- case 5 lead car appears25a
- case 6 zero relative v high gap
- case 7 zero relative v low gap
- case 8 sn high neg delta v25a
- case 9 ego stopped lead accelerating


Failed Tests:

- case 2 ego0 gap not desired25a

Chapter 2. case 10 lead gradually slows down

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_10_lead_g... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|--|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| Stateflow chart. Delete this object or <a (count:="" 2)<="" td=""> |
| Example: Stateflow chart. Delete this object or <a< td=""></a<> |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not used in the (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used in the (Count: 1) |
| href= "matlab: sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. (Count: 2) |
| Example: href= "matlab: sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. |
| |

Chapter 3. case 1 lead veh sudden stop 25a

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_1_lead_ve... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|---|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used (Count: 1) |
| in the Stateflow chart. Delete this (Count: 1) |
| object or configure the diagnostic. (Count: 2) |
| Example: object or configure the diagnostic. |
| used in the Stateflow chart. Delete this (Count: 1) |

Chapter 4. case 2 ego0 gap not desired25a

Status: Failed

Test Results:



Errors Summary

Error: non zero command acceleration: 0.600, should be zero (Count: 1)

Error: non zero command acceleration: 1.200, should be zero (Count: 1)

Error: non zero command acceleration: 1.350, should be zero (Count: 48)

Example: Error: non zero command acceleration: 1.350, should be zero

Warnings Summary

```
-->Stateflow Coder Warning :(SLSF Diagnostic)<a
href="matlab:sfprivate('sfOpenObjectBySId','case_2_ego0_ga... (Count: 1)
```

```
Unclassified Warnings
In construct_error (line 130) (Count: 2)
Example: In construct error (line 130)
In run_all_single_test (line 87)] (Count: 2)
Example: In run_all_single_test (line 87)]
In sfprivate (line 13) (Count: 2)
Example: In sfprivate (line 13)
[> In sldiagviewer.reportWarning (Count: 2)
Example: [> In sldiagviewer.reportWarning
[Warning: 'lead_acceleration_moving_average' is defined, but is not (Count: 1)
[Warning: 'lead_velocity_moving_average' is defined, but is not used (Count: 1)
in the Stateflow chart. Delete this (Count: 1)
object or configure the diagnostic. (Count: 2)
Example: object or configure the diagnostic.
```


used in the Stateflow chart. Delete this (Count: 1)

| Chapter 4. case 2 ego0 gap not desired25a |
|---|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

Chapter 5. case 3 lead rapid increase space

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_3_lead_ra... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|---|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used (Count: 1) |
| in the Stateflow chart. Delete this (Count: 1) |
| object or configure the diagnostic. (Count: 1) |
| this object or configure the diagnostic. (Count: 1) |
| used in the Stateflow chart. Delete (Count: 1) |

Chapter 6. case 4 lead disappears

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_4_lead_di... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|--|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| Stateflow chart. Delete this object or <a (count:="" 2)<="" td=""> |
| Example: Stateflow chart. Delete this object or <a< td=""></a<> |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not used in the (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used in the (Count: 1) |
| href= "matlab: sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. (Count: 2) |
| Example: href= "matlab: sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. |

Chapter 7. case 5 lead car appears 25a

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_5_lead_ca... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|--|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| Stateflow chart. Delete this object or <a (count:="" 1)<="" td=""> |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not used in (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used in the (Count: 1) |
| href= "matlab: sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. (Count: 1) |
| or configure the diagnostic. (Count: 1) |
| the Stateflow chart. Delete this object (Count: 1) |

Chapter 8. case 6 zero relative v high gap

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_6_zero_re... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|---|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used (Count: 1) |
| in the Stateflow chart. Delete this (Count: 1) |
| object or configure the diagnostic. (Count: 2) |
| Example: object or configure the diagnostic. |
| used in the Stateflow chart. Delete this (Count: 1) |

Chapter 9. case 7 zero relative v low gap

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_7_zero_re... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|--|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used in (Count: 1) |
| object or configure the diagnostic. (Count: 2) |
| Example: object or configure the diagnostic. |
| the Stateflow chart. Delete this (Count: 1) |
| used in the Stateflow chart. Delete this (Count: 1) |

Chapter 10. case 8 sn high neg delta v25a

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_8_sn_high... (Count: 1)

Unclassified Warnings


In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|---|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| [Warning: 'lead_acceleration_moving_average' is defined, but is not used (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not used in (Count: 1) |
| in the Stateflow chart. Delete this (Count: 1) |
| object or configure the diagnostic. (Count: 2) |
| Example: object or configure the diagnostic. |
| the Stateflow chart. Delete this (Count: 1) |

Chapter 11. case 9 ego stopped lead accelerating

Status: Passed with warnings

Test Results:



Warnings Summary

-->Stateflow Coder Warning :(SLSF Diagnostic)<a href="matlab:sfprivate('sfOpenObjectBySId','case_9_ego_sto... (Count: 1)

Unclassified Warnings

In construct_error (line 130) (Count: 2)

| In run_all_single_test (line 87)] (Count: 2) |
|---|
| Example: In run_all_single_test (line 87)] |
| In sfprivate (line 13) (Count: 2) |
| Example: In sfprivate (line 13) |
| [> In sldiagviewer.reportWarning (Count: 2) |
| Example: [> In sldiagviewer.reportWarning |
| |
| [Warning: 'lead_acceleration_moving_average' is defined, but is (Count: 1) |
| [Warning: 'lead_velocity_moving_average' is defined, but is not (Count: 1) |
| [warning: lead_velocity_moving_average is defined, but is not (count: 1) |
| internal.stateflow.dialogs.UnusedObjectDeleter.createDeleter('case_9_ego_stopped_lead_accelerating:5:37:7:::20')">Delete this object or <a (count:="" 1)<="" href="matlab: (Count: 1)</td></tr><tr><td></td></tr><tr><td>not used in the Stateflow chart<VALUE> |
| |
| sfprivate('openConfigParamsSFDiagnostics',21)">configure the diagnostic. (Count: 1) |
| this object or configure the diagnostic. (Count: 1) |
| |
| used in the Stateflow chart. Delete (Count: 1) |